

Superior Clamping and Gripping



Product data sheet

Universal gripper PGN-plus-P

Reliable. Robust. Flexible. Universal gripper PGN-plus-P

Universal 2-finger parallel gripper with permanent lubrication, high gripping force, and high maximum moments due to the use of a multi-tooth guidance

Field of application

Pneumatic universal gripper for handling of workpieces in universal applications. For universal use in clean to slightly dirty environments. Special versions available for dirty environments.

Advantages – Your benefits

Robust multi-tooth guidance for precise handling

High maximum moments possible suitable for using long gripper fingers

Lubricant pockets in the mult-tooth guidance ensure process reliability and extended maintenance intervals

Maximum piston surface area for maximum gripping forces

Mounting from two sides in three screw directions for universal and flexible gripper assembly

Air supply via hose-free direct connection or screw connections for universal and flexible gripper assembly

Comprehensive sensor accessory program for versatile querying possibilities and stroke position monitoring

Manifold options for special optimization for your specific case of application (dustproof, high-temperature, corrosion-protected, etc.)














Functional description

The piston is moved up and down by compressed air. The angled active surfaces of the wedge-hook produce a synchronized, parallel jaw motion.



1 Multi-tooth guidance

Maximum service life due to lubricant pockets in the robust multi-tooth guidance, and absorption of high forces and torques by means of the large guidance support

② Base jaw

with standardized screw connection diagram for the connection of the workpiece-specific gripper fingers

3 Bracket for sensors

Brackets for proximity switches and adjustable control cams in the housing

4 Housing

is weight-optimized due to the use of high-strength aluminum alloy

⑤ Centering and mounting possibilities for universal assembly of the gripper

6 Wedge-hook design

for high power transmission and minimal wear as a result of larger diagonal pull surfaces

7 Piston

Maximum force through maximum surface of drive piston

Detailed functional description

Dustproof version SD



The "dustproof" option increases the degree of protection against penetrating substances. This can either be ordered in a ready-mounted gripper version or else retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.

Gripping force maintenance version AS/IS




The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS version this acts as a closing force, and in the IS version as an opening force. The image shows the AS version. The gripping force maintenance can also be used to increase the gripping force or for one-way gripping.

- Multi-tooth guidance
- 2 Base jaw
- Bracket for sensors
- 4 Housing

- Centering and mounting possibilities
- 6 Wedge-hook design
- Piston
- 8 Gripping force maintenance


Settings of the control cams during monitoring with inductive proximity switches



Monitoring with inductive proximity switch can be performed as standard from size 64. In delivery state, the positions "gripper open" and "gripper closed" are preset with the control cams. The inductive sensors must be ordered separately and are slid into the housing up to the stop and clamped. In order to monitor any other position, such as "workpiece gripped" for example, both control cams can be individually set in the respective base jaws.

- Control cam preset for "gripper closed" position
- Control cam preset for "gripper open" position
- Holder with clamping screw for fixing the sensor
- Clamping screw for process-reliable fixing of the adjusted switching point
- Adjusting screw for setting any switching point

Optional mounting possibility under the cover sheet for customer-specific additional structure



In delivery state, a cover sheet is mounted to the gripper. This can be removed if necessary. Under the cover sheet are threads and fittings for mounting customer-specific designs for implementing additional functions.

- Additional centering or support of the workpiece
- 2 The cover plate (can be removed)
- **3** Ejector with external cylinder attached to the gripper

General notes about the series

Operating principle: Wedge gear with surface power

transmission

Housing material: Aluminum

Base jaw material: Steel

Actuation: pneumatic, with filtered compressed air as per

ISO 8573-1:2010 [7:4:4].

Warranty: 36 months

Service life characteristics: on request

Scope of delivery: Brackets for proximity switches, centering sleeves, 0-rings for direct connection, assembly instructions (operating manual with declaration of

incorporation is available online)

Gripping force maintenance: possible by using the version with mechanical gripping force maintenance or pressure

maintenance valve SDV-P

Gripping force: is the arithmetic sum of the individual force applied to each jaw at distance P (see illustration).

Finger length: is measured from the reference surface as the distance P in direction to the main axis.

The maximum permissible finger length applies until the nominal operating pressure is achieved. With higher pressures, the finger length must be reduced proportionally to the nominal operating pressure.

Repeat accuracy: is defined as a distribution of the end Position for 100 consecutive strokes.

Workpiece weight: is calculated for force-fit gripping with a coefficient of static friction of 0.1 and a safety factor of 2 against workpiece slippage at acceleration due to gravity g. For form-fit or capture gripping, there are significantly higher permissible workpiece weights.

Closing and opening times: are movement times of the base jaws only, without application–specific gripper fingers. Valve switching times, hose fill times, or PLC reaction times are not included, and are to be considered when cycle times are calculated.



Application example

Handling tool for loading and unloading raw and finished parts and compensation of inaccurate position. A sensor distributor is used for routing signals through a cable.

- Sensor distributor V4
- Tolerance compensation unit TCU-Z
- Universal gripper PGN-plus-P
- IN sensors
- Universal rotary actuator SRM

SCHUNK offers more ...

The following components make the product even more productive – the suitable addition for the highest functionality, flexibility, reliability, and controlled production.



① For more information on these products can be found on the following product pages or at schunk.com.

Options and special information

Gripping force maintenance version AS/IS: The mechanical gripping force maintenance version ensures minimum gripping force even in the event of a pressure drop. In the AS/S version this acts as a closing force, in the IS version as an opening force.

High-temperature version V/HT: for use in hot environments

Precision version P: for the highest accuracy

Anti-corrosion version K: for use in corrosion-inducing atmospheres

ATEX version EX: for explosive environments

Dustproof version SD: absolutely dustproof, increased degree of protection against ingress of materials.


Integrated air purge connection: impedes the ingress of dirt into the inside of the gripper

Food-grade lubrication: The product contains food-compliant lubricants as standard. The requirements of EN 1672-2:2020 are not fully met. The relevant NSF certificates are available at https://info.nsf.org/USDA/Listings.asp using the lubricant information in the operating manual.

Additional versions: Various options can be combined with each other.

SCHUNK gripper PGN-plus-P

Overview Accessories



8

PGN-plus-P

Universal 2-finger parallel gripper with a high gripping force and high maximum moments due to the use of a multi-tooth guidance

Sensor system

2 IN ...

Inductive proximity switch with molded cable and straight cable outlet

Inductive proximity switch with molded cable and laberal cable outlet

IN-C 80

Inductive proximity switch, directly pluggable

FPS

Flexible position sensor for monitoring up to five different, freely selectable positions

APS-Z80

Inductive position sensor for precise position detection of the gripper jaws with analog output

APS-M1S

Mechanical measuring system for precise position detaction of the gripper jaw with analog output

8 MMS 22

Magnetic switch with straight cable outlet for monitoring a position

MMS 22-PI1

Magnetic switch with straight cable outlet for monitoring a freely programmable position

9 MMS 22-PI2

Magnetic switch with straight cable outlet for monitoring two freely programmable position

10 MMS 22-PI1-HD

MMS 22-PI1 in robust design

MMS 22-PI2-HD

MMS 22-PI2 in robust design

1 MMS 22-SA

Magnetic switch with lateral cable outlet for monitoring a position

MMS 22-PI1-SA

Magnetic switch with side cable outlet for monitoring a freely programmable position

MMS-P

Magnetic switch with straight cable outlet for monitoring two freely programmable position

B MMS-A

Analog magnetic switch with straight cable outlet for measuring the gripper jaw position with analog output and teach function

Complementary products

@ CWS

Manual change system with integrated air feed-through for simple exchange of the handling components

🚯 TCU

Tolerance compensation unit for compensating small tolerances in the plane

6 SDV-P-E-P

Pressure maintenance valve for temporary force and position maintenance

⚠ AGE

Compensation unit for compensation of large tolerances along the X and Y axes

B ASG

Adapter plate for combining various automation components in the modular system

📵 CLM

Linear module with pneumatic drive and scope-free pre-loaded junction rollers

4 HUE

Sleeve for protection against dirt

SAD

Dustproof version, retrofit kit

Finger Accessories

UZB

The universal intermediate jaw allows fast tool-free and reliable plugging and shifting of top jaws at the gripper.

BSWS-AR

Adapter pin of the jaw quick-change system for fast, manual change of top jaws

BSWS-B

Locking mechanism of the jaw quick-change system for fast, manual exchange of top jaws

BSWS-A

Adapter pin of the jaw quick-change system for adaptation to the customized finger $\,$

- Customized fingers
- BSWS-ABR

Finger blank made of aluminum with interface to the jaw quick-change system

BSWS-SBR

Finger blank made of steel with interface to the jaw quick-change system

BSWS-UR

Locking mechanism for the integration of the jaw quickchange system into customized fingers

ABR/SBF


Finger blanks made of steel or aluminum with standardized screw connection diagram

30 ZBA


Intermediate jaws for reorientation of the mounting surface




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 40 | PGN-plus-P 40-AS | PGN-plus-P 40-IS |
|------------------------------------|-------|----------------|------------------|------------------|
| ID | | 0318448 | 0318450 | 0318452 |
| Stroke per jaw | [mm] | 2.5 | 2.5 | 2.5 |
| Closing/opening force | [N] | 180/200 | 235/- | -1260 |
| Min. spring force | [N] | | 55 | 60 |
| Weight | [kg] | 0.08 | 0.1 | 0.1 |
| Recommended workpiece weight | [kg] | 0.9 | 0.9 | 0.9 |
| Cylinder volume per double stroke | [cm³] | 4 | 8 | 10 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.015/0.015 | 0.015/0.03 | 0.03/0.015 |
| Closing/opening time with spring | [s] | | 0.03 | 0.03 |
| Max. permissible finger length | [mm] | 65 | 60 | 60 |
| Max. permissible weight per finger | [kg] | 0.12 | 0.12 | 0.12 |
| IP protection class | | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.01 | 0.01 | 0.01 |
| Dimensions X x Y x Z | [mm] | 50 x 25 x 24.7 | 50 x 25 x 33.7 | 50 x 25 x 33.7 |
| Options and their characteristics | | | | |
| Dustproof version | | 1317458 | 1317463 | 1317466 |
| IP protection class | | 64 | 64 | 64 |
| Weight | [kg] | 0.1 | 0.12 | 0.12 |
| Corrosion-protected version | | 1317436 | 1317437 | 1317439 |
| High-temperature version | | 1317423 | 1317428 | 1317431 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 |
| Precision version | | 1317451 | 1317454 | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- (2) Finger connection
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22...
- ©2 Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection






 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M2



The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.


Gripping force maintenance version AS/IS



10 Projection applies only for AS version

The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




For mounting screw connection 20 For version AS/IS diagram, see basic version

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|-------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 40 | 1347469 |

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.


Precision version



- 20 For version AS/IS72 Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

SDV-P pressure maintenance valve



(4) Grippers


90 SDV-P pressure maintenance valve

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter | | |
|---|---------|---------------------------|--|--|
| | | [mm] | | |
| Pressure maintenance valve | | | | |
| SDV-P 04 | 0403130 | 6 | | |
| Pressure maintenance valve with air bleed screw | | | | |
| SDV-P 04-E | 0300120 | 6 | | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

Protective cover HUE PGN-plus 40



9 For mounting screw connection diagram, see basic version

The HUE protective cover fully protects the gripper against external influences. The cover is suitable for applications of up to IP65 if an additional sealing of the cover bottom is provided. For detailed information, please see the HUE series. The connection diagram shifts by the height of the intermediate jaw.


| Description | ID | IP protection class |
|------------------|---------|---------------------|
| Protection cover | | |
| HUE PGN-plus 40 | 0371490 | 65 |

The HUE protective cover is not suitable for use on grippers with gripping force maintenance. An inductive monitoring of the gripper in connection with the HUE protective cover is not possible. SCHUNK recommends the use of magnetic sensors that are approved for the respective gripper variant.

PGN-plus-P 40

Universal gripper

UZB 40 universal intermediate jaw



- 1 Gripper connection
- 2 Finger connection
- (54) Optional right or left connection
- 57 Locking
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The drawing shows the UZB universal intermediate jaw.

| Description | ID | Grid dimension | |
|------------------------|---------|----------------|--|
| | | [mm] | |
| Universal intermediate | jaw | | |
| UZB 40 | 0300040 | 1 | |
| Finger blank | | | |
| ABR-PGZN-plus 40 | 0300008 | | |
| SBR-PGZN-plus 40 | 0300018 | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------|-------------|--|
| PGN-plus-P | 40 | -1 (6 bar) | | |
| PGN-plus-P | 40 | -1-AS/1-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Finger blanks ABR/SBR-PGZN-plus 40




2 Finger connection

72 Fit for centering sleeves

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 40 | 0300008 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 40 | 0300018 | Steel (1.7131) | 1 |

Compensation unit AGE-F




90 Monitoring

The unit has direct connection possibilities for different grippers of the PGN-plus, PGN-plus-P and PZN-plus series. For more detailed information, please refer to the main view.

| Description | ID | Compensation XY | Reset force | Often combined |
|-------------------|---------|--------------------|-------------|-------------------|
| | | [mm] | [N] | |
| Compensation unit | | | | |
| AGE-F-XY-031-1 | 0324900 | ± 1.5 | 1.5 | |
| AGE-F-XY-031-2 | 0324901 | ± 1.5 | 4 | |
| AGE-F-XY-031-3 | 0324902 | ± 1.5 | 5.5 | • |

① Due to the interfering contour, monitoring of the gripper is not possible.


Modular Assembly Automation



- (4) Grippers
- (91) ASG adapter plate
- © Linear module CLM/KLM/LM/ELP/ ELM/ELS/HLM

Grippers and linear modules can be combined with standard adapter plates from the modular assembly system. For more information see our main catalog "Modular Assembly Automation".

Adapter plate for PGN-plus 40



- 1 Robot-side connection
- 72 Fit for centering sleeves
- 2 Tool-side connection
- 80 Depth of the centering sleeve hole in the counter part


The adapter plate has integrated air feed-throughs in order to be able to use the hose-free direct connection of the appropriate gripper.

| Description | ID |
|-----------------|---------|
| Tool side | |
| A-CWA-050-040-P | 0305754 |

PGN-plus-P 40

Universal gripper

Electronic magnetic switch MMS




- 17 Cable outlet
- 91) Sensor MMS 22...-SA
- 90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| 301032 | |
|--|----------------------|
| 301032 | |
| | • |
| 301034 | |
| teral cable c | outlet |
| 301042 | • |
| 301044 | |
| | |
| 301622 | • |
| 301623 | |
| 301594 | |
| 301502 | |
| | |
| 301463 | |
| | |
| 301495 | |
| 301496 | |
| 301497 | • |
| | |
| 301775 | • |
| 301746 | |
| 301751 | |
| it 1333333333333333333333333333333333333 | eral cable of 101042 |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1



(17) Cable outlet

(91) Sensor MMS 22 ..-PI1-...-SA


90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | |
|---|----------------|----------------|--|--|--|
| Programmable magnetic switch | | | | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • | | | |
| MMSK 22-PI1-S-PNP | 0301162 | | | | |
| Programmable magnetic switch | with lateral c | able outlet | | | |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • | | | |
| MMSK 22-PI1-S-PNP-SA | 0301168 | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • | | | |
| MMSK 22-PI1-S-PNP-HD | 0301112 | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI2



(17) Cable outlet


90 MMS 22...-PI2-... sensor

Position monitoring with two programmable positions per sensor and electronics integrated in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | |
|---|----------------|----------------|--|--|--|
| Programmable magnetic switch | | | | | |
| MMS 22-PI2-S-M8-PNP | 0301180 | • | | | |
| MMSK 22-PI2-S-PNP | 0301182 | | | | |
| Programmable magnetic switch | with lateral c | able outlet | | | |
| MMS 22-PI2-S-M8-PNP-SA | 0301186 | • | | | |
| MMSK 22-PI2-S-PNP-SA | 0301188 | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | |
| MMS 22-PI2-S-M8-PNP-HD | 0301130 | • | | | |
| MMSK 22-PI2-S-PNP-HD | 0301132 | | | | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

MMS-P programmable magnetic switch




(74) Limit stop for sensor

Position monitoring with two programmable positions per sensor. End position monitoring for mounting in the C-slot.

| Description | ID | Often combined | | | | |
|------------------------------|------------------------------|----------------|--|--|--|--|
| Programmable magnetic switch | Programmable magnetic switch | | | | | |
| MMSK-P 22-S-PNP | 0301371 | | | | | |
| MMS-P 22-S-M8-PNP | 0301370 | • | | | | |
| Connection cables | | | | | | |
| KA GLN0804-LK-00500-A | 0307767 | • | | | | |
| KA GLN0804-LK-01000-A | 0307768 | | | | | |
| KA WLN0804-LK-00500-A | 0307765 | | | | | |
| KA WLN0804-LK-01000-A | 0307766 | | | | | |
| Clip for connector/socket | | | | | | |
| CLI-M8 | 0301463 | | | | | |
| Sensor distributor | | | | | | |
| V2-M8-4P-2XM8-3P | 0301380 | | | | | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

Analog position sensor MMS-A




74) Limit stop for sensor

Non-contact measuring, analog multi-position monitoring for any number of positions, easy to assemble in the C-slot. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the chart provided, teaching is only possible with the ST teaching tools.

| Description | ID | |
|------------------------|---------|--|
| Analog position sensor | | |
| MMS 22-A-10V-M08 | 0315825 | |
| MMS 22-A-10V-M12 | 0315828 | |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

Flexible position sensor with MMS-A




- (74) Limit stop for sensor
- (91) FPS-F5 evaluation electronic
- 90 MMS 22-A-... sensor
- 92 Connection cables

Flexible position monitoring of up to five positions. Sensor can be taught using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | |
|------------------------|---------|--|
| Analog position sensor | | |
| MMS 22-A-05V-M08 | 0315805 | |
| Evaluation electronics | | |
| FPS-F5 | 0301805 | |
| Sensor Teaching Tool | | |
| MT-MMS 22-PI | 0301030 | |
| Connection cables | | |
| KA BG16-L 12P-1000 | 0301801 | |

When using an FPS system, one MMS 22-A-05V and one evaluation electronics (FPS-F5) are required per each gripper, as well as an attachment kit (AS), if listed. On option, cable extensions (KV) are available - see catalog chapter "Accessories."

Programmable magnetic switch MMS-I0-Link



(74) Limit stop for sensor


Sensor for multi-position monitoring through detection of the complete gripper stroke. The sensor is mounted directly in the C-slot of the gripper. The sensor is programmed for the gripper via the IO-Link interface, Magnet teaching tool MT (included in scope of delivery; ID 0301030) or the ST plug teaching tool (not included in scope of delivery; ID 0301026). An IO-Link master is required for operation.

| Description | ID | |
|------------------------------|---------|--|
| Programmable magnetic switch | | |
| MMS 22-I0L-M08 | 0315830 | |
| MMS 22-I0L-M12 | 0315835 | |


① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 50-1 | PGN-plus-P 50-2 | PGN-plus-P 50-1-AS | PGN-plus-P 50-2-AS | PGN-plus-P 50-1-IS | PGN-plus-P 50-2-IS |
|------------------------------------|-------|--------------------|--------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| ID | | 0318472 | 0318473 | 0318474 | 0318475 | 0318476 | 0318477 |
| Stroke per jaw | [mm] | 4 | 2 | 4 | 2 | 4 | 2 |
| Closing/opening force | [N] | 220/235 | 380/410 | 295/- | 490/- | -/300 | -/520 |
| Min. spring force | [N] | | | 75 | 110 | 65 | 110 |
| Weight | [kg] | 0.17 | 0.17 | 0.2 | 0.2 | 0.2 | 0.2 |
| Recommended workpiece weight | [kg] | 1.1 | 1.9 | 1.1 | 1.9 | 1.1 | 1.9 |
| Cylinder volume per double stroke | [cm³] | 6 | 6 | 10 | 10 | 12 | 12 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.015/0.015 | 0.015/0.015 | 0.015/0.025 | 0.015/0.025 | 0.025/0.015 | 0.025/0.015 |
| Closing/opening time with spring | [s] | | | 0.03 | 0.03 | 0.03 | 0.03 |
| Max. permissible finger length | [mm] | 80 | 75 | 75 | 70 | 75 | 70 |
| Max. permissible weight per finger | [kg] | 0.2 | 0.2 | 0.2 | 0.2 | 0.2 | 0.2 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 |
| Dimensions X x Y x Z | [mm] | 65 x 30 x 31 | 65 x 30 x 31 | 65 x 30 x 47 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1317516 | 1317527 | 1317531 | 1317534 | 1317539 | 1317541 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 0.21 | 0.21 | 0.24 | 0.24 | 0.24 | 0.24 |
| Corrosion-protected version | | 38318472 | 38318473 | 38318474 | 38318475 | 38318476 | 38318477 |
| High-temperature version | | 39318472 | 39318473 | 39318474 | 39318475 | 39318476 | 39318477 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 0318478 | 0318479 | 0318480 | 0318481 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- 2 Finger connection
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22..
- 92 Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection






 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M3



The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.


Gripping force maintenance version AS/IS



10 Projection applies only for AS

The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as $\,$ an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




(9) For mounting screw connection (20) For version AS/IS diagram, see basic version

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|-------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 50 | 1347474 |

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.

SDV-P pressure maintenance valve



(4) Grippers


90 SDV-P pressure maintenance valve

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter | |
|---|---------|---------------------------|--|
| | | [mm] | |
| Pressure maintenance valve | | | |
| SDV-P 04 | 0403130 | 6 | |
| Pressure maintenance valve with air bleed screw | | | |
| SDV-P 04-E | 0300120 | 6 | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

Precision version




- 20 For version AS/IS
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

PGN-plus-P 50

Universal gripper

Pneumatic positioning device PPD




The PPD allows flexibility in all applications with pneumatic grippers through free positioning, gripping force and speed adjustment.

| Description | ID | | | |
|--|---------|--|--|--|
| Pneumatic positioning device | | | | |
| PPD 10-IOL | 1540698 | | | |
| Adapter | | | | |
| A GGN0804-1204-A | 1540691 | | | |
| 10-Link connection cable | | | | |
| KA GGN1205-1212-IOL-00100-A | 1540697 | | | |
| Voltage supply connection cable – cable track compatible | | | | |
| KA GLN12B05-LK-01000-A | 1540660 | | | |
| Cable extension | | | | |
| KV GGN0804-I0-00150-A | 1540662 | | | |
| KV GGN0804-10-00300-A | 1540663 | | | |
| Assembly set | | | | |
| Assembly set PPD | 1540705 | | | |

 $\ \textcircled{\ \ }$ In addition to the PPD, a position sensor (SCHUNK IO-Link sensor or analog sensor (4...20 mA)) is required.

Protective cover HUE PGN-plus 50




9 For mounting screw connection diagram, see basic version

The HUE protective cover fully protects the gripper against external influences. The cover is suitable for applications of up to IP65 if an additional sealing of the cover bottom is provided. For detailed information, please see the HUE series. The connection diagram shifts by the height of the intermediate jaw.

| Description | ID | IP protection class |
|------------------|---------|---------------------|
| Protection cover | | |
| HUE PGN-plus 50 | 0371479 | 65 |

The HUE protective cover is not suitable for use on grippers with gripping force maintenance. An inductive monitoring of the gripper in connection with the HUE protective cover is not possible. SCHUNK recommends the use of magnetic sensors that are approved for the respective gripper variant.

BSWS jaw quick-change jaw systems



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | | | |
|---|-------------------------------------|-------------------|--|--|--|--|
| Jaw quick-change system ada | Jaw quick-change system adapter pin | | | | | |
| BSWS-A 50 | 0303020 | 2 | | | | |
| BSWS-AR 50 | 0300091 | 2 | | | | |
| Quick-change jaw system base | | | | | | |
| BSWS-B 50 | 0303021 | 1 | | | | |
| Jaw quick-change system finger blank | | | | | | |
| BSWS-ABR-PGZN-plus 50 | 0300071 | 1 | | | | |
| BSWS-SBR-PGZN-plus 50 | 0300081 | 1 | | | | |
| Jaw quick-change system locking mechanism | | | | | | |
| BSWS-UR 50 | 0302990 | 1 | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|------------|--|---------------|--|
| PGN-plus-P | 50 | -1 (6 bar) | | |
| PGN-plus-P | 50 | -1-AS/1-IS (6 ba | r) ••• | |
| PGN-plus-P | 50 | -2 (6 bar) | | |
| PGN-plus-P | 50 | -2-AS/2-IS (6 ba | r) ••• | |
| Legend | | | | |
| | Can be cor | Can be combined without restrictions | | |
| | Use with r | Use with restrictions (see loading limits) | | |
| 0000 | cannot be | cannot be combined | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-M



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| • • | | | | | | |
|---|-------------------------------------|-------------------|--|--|--|--|
| Description | ID | Scope of delivery | | | | |
| Jaw quick-change system adapt | Jaw quick-change system adapter pin | | | | | |
| BSWS-A 50 | 0303020 | 2 | | | | |
| BSWS-AR 50 | 0300091 | 2 | | | | |
| Quick-change jaw system base | | | | | | |
| BSWS-BM 50 | 1313899 | 1 | | | | |
| Jaw quick-change system finger blank | | | | | | |
| BSWS-ABRM-PGZN-plus 50 | 1420850 | 1 | | | | |
| Jaw quick-change system locking mechanism | | | | | | |
| BSWS-URM 50 | 1380614 | 1 | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | | |
|------------|--|--------------------------------------|-------------|--|--|
| PGN-plus-P | 50 | -1 (6 bar) | | | |
| PGN-plus-P | 50 | -1-AS/1-IS (6 bar) | | | |
| PGN-plus-P | 50 | -2 (6 bar) | | | |
| PGN-plus-P | 50 | -2-AS/2-IS (6 bar) | | | |
| Legend | | | | | |
| | Can be combined w | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | | |
| 0000 | cannot be combine | cannot be combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-R



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | | |
|--|----------|-------------------|--|--|--|
| Jaw quick-change system ada | pter pin | | | | |
| BSWS-AR 50 | 0300091 | 2 | | | |
| Quick-change jaw system base | 2 | | | | |
| BSWS-BR 50 | 1555889 | 1 | | | |
| Storage system | | | | | |
| BSWS-SR 50 | 1555948 | 1 | | | |
| Attachment kit for proximity s | witch | | | | |
| AS-IN40-BSWS-SR 50/64 | 1561455 | 1 | | | |
| Inductive proximity switch | | | | | |
| IN 40-S-M12 | 0301574 | | | | |
| IN 40-S-M8 | 0301474 | | | | |
| INK 40-S | 0301555 | | | | |
| Inductive proximity switch with lateral cable outlet | | | | | |
| IN 40-S-M12-SA | 0301577 | | | | |
| INK 40-S-SA | 0301565 | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | | |
|------------|-------------|--|---------------|--|--|
| PGN-plus-P | 50 | -1 (6 bar) | | | |
| PGN-plus-P | 50 | -1-AS/1-IS (6 ba | r) ••• | | |
| PGN-plus-P | 50 | -2 (6 bar) | | | |
| PGN-plus-P | 50 | -2-AS/2-IS (6 ba | nr) | | |
| Legend | | | | | |
| | Can be con | Can be combined without restrictions | | | |
| | Use with re | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be | combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

ZBA-L-plus 50 intermediate jaws




- 2 Finger connection
- (56) Included in the scope of delivery
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 81) Not included in the scope of delivery

The optional ZBA-L-plus intermediate jaws allow the screw connection diagram of the top jaws to be rotated by 90°. This makes it easier to design and produce top jaws (particularly for long versions) because no deep through-bores are required.

| Description | ID | | Finger interface | Scope of delivery |
|------------------|---------|----------|---------------------|-------------------|
| Intermediate jaw | | | | |
| ZBA-L-plus 50 | 0311712 | Aluminum | PGN-plus 50 | 1 |

UZB 50 universal intermediate jaw



- 1 Gripper connection
- 2 Finger connection
- (54) Optional right or left connection
- 57 Locking
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The drawing shows the UZB universal intermediate jaw.

| 0 | | • |
|------------------------|---------|----------------|
| Description | ID | Grid dimension |
| | | [mm] |
| Universal intermediate | jaw | |
| UZB 50 | 0300041 | 1.5 |
| Finger blank | | |
| ABR-PGZN-plus 50 | 0300009 | |
| SBR-PGZN-plus 50 | 0300019 | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|-------------|--|-------------|--|
| PGN-plus-P | 50 | -1 (6 bar) | | |
| PGN-plus-P | 50 | -1-AS/1-IS (6 bar |) ==== | |
| PGN-plus-P | 50 | -2 (6 bar) | | |
| PGN-plus-P | 50 | -2-AS/2-IS (6 bar |) 0000 | |
| Legend | | | | |
| | Can be con | Can be combined without restrictions | | |
| | Use with re | Use with restrictions (see loading limits) | | |
| 0000 | cannot be | cannot be combined | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Finger blanks ABR/SBR-PGZN-plus 50




(2) Finger connection

(72) Fit for centering sleeves

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 50 | 0300009 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 50 | 0300019 | Steel (1.7131) | 1 |

Compensation unit AGE-F




90 Monitoring

The unit has direct connection possibilities for different grippers of the PGN-plus, PGN-plus-P and PZN-plus series. For more detailed information, please refer to the main view.

| Description | ID | Compensation XY | Reset force | Often combined |
|-------------------|---------|--------------------|-------------|----------------|
| | | [mm] | [N] | |
| Compensation unit | | | | |
| AGE-F-XY-040-1 | 0324920 | ± 2 | 3 | |
| AGE-F-XY-040-2 | 0324921 | ± 2 | 4 | |
| AGE-F-XY-040-3 | 0324922 | ± 2 | 4.5 | • |

① Due to the interfering contour, monitoring of the gripper is not possible.

Tolerance compensation unit TCU




90 Monitoring of locking

Grippers can be directly mounted without an adapter plate. Tolerance compensation unit and gripper have an identical screw connection diagram. Therefore the tolerance compensation units can be assembled later. Please consider the additional assembly height of the tolerance compensation unit. For details please refer to our catalog robot accessories.

| Description | ID | Locking | Deflection |
|-------------------|---------|---------|---------------|
| Compensation unit | | | |
| TCU-P-050-3-0V | 0324757 | no | ±1°/±1°/±1,5° |

Adapter plate for PGN-plus 50




- (1) Robot-side connection
- (72) Fit for centering sleeves
- 2 Tool-side connection
- 80 Depth of the centering sleeve hole in the counter part

The adapter plate has integrated air feed-throughs in order to be able to use the hose-free direct connection of the appropriate gripper.

| Description | ID | |
|-----------------|---------|--|
| Tool side | | |
| A-CWA-064-050-P | 0305768 | |

Compact change system for grippers




- 4 Grippers
- **92** A-CWA adapter plate
- 90 CWA compact change adapter
- (93) CWA compact change adapter
- (91) CWK compact change master
- (94) CWK compact change master

Grippers can be directly mounted without an adapter plate. For details see our catalog Gripping or Robot Accessories.

| Description | ID |
|--------------------|---------|
| Tool side | |
| A-CWA-064-050-P | 0305768 |
| CWA compact change | adapter |
| CWA-050-P | 0305751 |
| CWK compact change | master |
| CWK-050-P | 0305750 |


Modular Assembly Automation



- 4 Grippers
- 91) ASG adapter plate
- 90 Linear module CLM/KLM/LM/ELP/ ELM/ELS/HLM

Grippers and linear modules can be combined with standard adapter plates from the modular assembly system. For more information see our main catalog "Modular Assembly Automation".

Electronic magnetic switch MMS




- (17) Cable outlet
- 91) Sensor MMS 22...-SA
- 90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|-----------------------------------|---------|----------------|
| Electronic magnetic switch | 10 | orten combined |
| MMS 22-S-M8-PNP | 0301032 | • |
| MMSK 22-S-PNP | 0301032 | • |
| Electronic magnetic switches with | | nutlet |
| MMS 22-S-M8-PNP-SA | 0301042 | - Control |
| MMSK 22-S-PNP-SA | 0301012 | |
| Connection cables | 0301044 | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | • |
| KA BW08-L 3P-0300-PNP | 0301523 | |
| KA BW08-L 3P-0500-PNP | 0301594 | |
| Clip for connector/socket | 0301302 | |
| CLI-M8 | 0301463 | |
| Cable extension | 0301403 | |
| | 0201405 | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| Sensor distributor | | |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1




- (17) Cable outlet
- **91** Sensor MMS 22 ..-PI1-...-SA
- 90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| | | · · | | | | |
|---|---------|----------------|--|--|--|--|
| Description | ID | Often combined | | | | |
| Programmable magnetic switch | | | | | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • | | | | |
| MMSK 22-PI1-S-PNP | 0301162 | | | | | |
| Programmable magnetic switch with lateral cable outlet | | | | | | |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • | | | | |
| MMSK 22-PI1-S-PNP-SA | 0301168 | | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | | |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • | | | | |
| MMSK 22-PI1-S-PNP-HD | 0301112 | | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI2



(17) Cable outlet


90 MMS 22...-PI2-... sensor

Position monitoring with two programmable positions per sensor and electronics integrated in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined |
|------------------------------|----------------|-----------------|
| Programmable magnetic switch | | |
| MMS 22-PI2-S-M8-PNP | 0301180 | • |
| MMSK 22-PI2-S-PNP | 0301182 | |
| Programmable magnetic switch | with lateral c | able outlet |
| MMS 22-PI2-S-M8-PNP-SA | 0301186 | • |
| MMSK 22-PI2-S-PNP-SA | 0301188 | |
| Programmable magnetic switch | with stainless | s steel housing |
| MMS 22-PI2-S-M8-PNP-HD | 0301130 | • |
| MMSK 22-PI2-S-PNP-HD | 0301132 | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

MMS-P programmable magnetic switch




74) Limit stop for sensor

Position monitoring with two programmable positions per sensor. End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|-----------------------------|---------|----------------|
| Programmable magnetic switc | h | |
| MMSK-P 22-S-PNP | 0301371 | |
| MMS-P 22-S-M8-PNP | 0301370 | • |
| Connection cables | | |
| KA GLN0804-LK-00500-A | 0307767 | • |
| KA GLN0804-LK-01000-A | 0307768 | |
| KA WLN0804-LK-00500-A | 0307765 | |
| KA WLN0804-LK-01000-A | 0307766 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Sensor distributor | | |
| V2-M8-4P-2XM8-3P | 0301380 | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

Analog position sensor MMS-A




- (74) Limit stop for sensor
- Flow control coupling, Ø 0.8 mm, for teaching process (ID 9953035/not included in the scope of delivery)
- (91) Air connection (not included in the scope of delivery)

Non-contact measuring, analog multi-position monitoring for any number of positions, easy to assemble in the C-slot. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the chart provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-10V-M08 | 0315825 |
| MMS 22-A-10V-M12 | 0315828 |

① One sensor is required per unit. The output voltage of the sensor differs according to the unit and is typically between 0.3 and 10 V. For teaching the sensor, a flow control coupling is required to reduce the speed during the teaching process. The resolution of the sensor can be smaller in the peripheral areas of the gripper. For further information on the product, see operating manual.

Flexible position sensor with MMS-A




- 74) Limit stop for sensor
- 90 MMS 22-A-... sensor
- (91) FPS-F5 evaluation electronic
- (92) Connection cables
- (93) Flow control coupling, Ø 0.8 mm, for teaching process (ID 9953035/not included in the scope of delivery)
- (94) Air connection (not included in the scope of delivery)

Flexible position monitoring of up to five positions. Sensor can be taught using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-05V-M08 | 0315805 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Sensor Teaching Tool | |
| MT-MMS 22-PI | 0301030 |
| Connection cables | |
| KA BG16-L 12P-1000 | 0301801 |

When using an FPS system, an MMS 22-A-05V, and evaluation electronics (FPS-F5) are required for each gripper. For teaching the sensor, a flow control coupling is required to reduce the speed during the teaching process. The resolution of the sensor can be smaller in the peripheral areas of the gripper. For further information on the product, see operating manual.

Programmable magnetic switch MMS-IO-Link



74 Limit stop for sensor


Sensor for multi-position monitoring through detection of the complete gripper stroke. The sensor is mounted directly in the C-slot of the gripper. The sensor is programmed for the gripper via the IO-Link interface, Magnet teaching tool MT (included in scope of delivery; ID 0301030) or the ST plug teaching tool (not included in scope of delivery; ID 0301026). An IO-Link master is required for operation.

| Description | ID | |
|------------------------------|---------|--|
| Programmable magnetic switch | | |
| MMS 22-I0L-M08 | 0315830 | |
| MMS 22-I0L-M12 | 0315835 | |


① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 64-1 | PGN-plus-P 64-2 | PGN-plus-P 64-1-AS | PGN-plus-P 64-2-AS | PGN-plus-P 64-1-IS | PGN-plus-P 64-2-IS |
|------------------------------------|-------|--------------------|--------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| ID | | 0318496 | 0318497 | 0318498 | 0318499 | 0318500 | 0318501 |
| Stroke per jaw | [mm] | 6 | 3 | 6 | 3 | 6 | 3 |
| Closing/opening force | [N] | 350/375 | 720/770 | 470/- | 920/- | -/530 | -/1050 |
| Min. spring force | [N] | | | 120 | 200 | 155 | 280 |
| Weight | [kg] | 0.27 | 0.27 | 0.35 | 0.35 | 0.35 | 0.35 |
| Recommended workpiece weight | [kg] | 1.75 | 3.6 | 1.75 | 3.6 | 1.75 | 3.6 |
| Cylinder volume per double stroke | [cm³] | 15 | 15 | 24 | 24 | 27 | 27 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.02/0.02 | 0.02/0.02 | 0.02/0.04 | 0.02/0.04 | 0.04/0.02 | 0.04/0.02 |
| Closing/opening time with spring | [s] | | | 0.07 | 0.07 | 0.07 | 0.07 |
| Max. permissible finger length | [mm] | 100 | 90 | 90 | 85 | 90 | 85 |
| Max. permissible weight per finger | [kg] | 0.4 | 0.4 | 0.4 | 0.4 | 0.4 | 0.4 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 |
| Dimensions X x Y x Z | [mm] | 76 x 36 x 39 | 76 x 36 x 39 | 76 x 36 x 57 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1317542 | 1317543 | 1317545 | 1317548 | 1317549 | 1317558 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 0.34 | 0.34 | 0.42 | 0.42 | 0.42 | 0.42 |
| Corrosion-protected version | | 38318496 | 38318497 | 38318498 | 38318499 | 38318500 | 38318501 |
| High-temperature version | | 39318496 | 39318497 | 39318498 | 39318499 | 39318500 | 39318501 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 0318502 | 0318503 | 0318504 | 0318505 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- (2) Finger connection
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22..
- (91) Sensor IN ...
- 92 Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection






 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M3



The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.


Gripping force maintenance version AS/IS



10 Projection applies only for AS version

The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- (9) For mounting screw connection diagram, see basic version
- 15) Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.


Precision version



- 20 For version AS/IS
- 72 Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

SDV-P pressure maintenance valve



4 Grippers


90 SDV-P pressure maintenance

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter | | |
|---|---------|---------------------------|--|--|
| | | [mm] | | |
| Pressure maintenanc | e valve | | | |
| SDV-P 04 | 0403130 | 6 | | |
| SDV-P 07 | 0403131 | 8 | | |
| Pressure maintenance valve with air bleed screw | | | | |
| SDV-P 04-E | 0300120 | 6 | | |
| SDV-P 07-E | 0300121 | 8 | | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

SDV-P E-P pressure maintenance valve




- (3) Adapter
- 90 SDV-P E-P pressure maintenance valve
- 91) 2-finger parallel gripper PGN-plus/PGN-plus-P
- 92 2-finger parallel gripper JGP-P
- 93) 2-finger angular gripper PWG-plus
- (94) 2-finger parallel gripper PGB
- 95) Sealed DPG-plus gripper

The SDV-P E-P pressure maintenance valves ensure that the pressure in the piston chamber is maintained temporarily during an emergency stop. SDV-P E-P can be directly connected to the listed grippers without the need for additional pneumatic hoses.

| Description | ID |
|------------------|------------|
| Pressure mainten | ance valve |
| SDV-P 64-E-P | 0300124 |

Pneumatic positioning device PPD




The PPD allows flexibility in all applications with pneumatic grippers through free positioning, gripping force and speed adjustment.

| Description | ID | |
|--|---------------|-------|
| Pneumatic positioning device | | |
| PPD 10-IOL | 1540698 | |
| Adapter | | |
| A GGN0804-1204-A | 1540691 | |
| 10-Link connection cable | | |
| KA GGN1205-1212-IOL-00100-A | 1540697 | |
| Voltage supply connection cable - cabl | e track compa | tible |
| KA GLN12B05-LK-01000-A | 1540660 | |
| Cable extension | | |
| KV GGN0804-I0-00150-A | 1540662 | |
| KV GGN0804-10-00300-A | 1540663 | |
| Assembly set | | |
| Assembly set PPD | 1540705 | |

① In addition to the PPD, a position sensor (SCHUNK IO-Link sensor or analog sensor (4...20 mA)) is required.

Protective cover HUE PGN-plus 64




9 For mounting screw connection diagram, see basic version

The HUE protective cover fully protects the gripper against external influences. The cover is suitable for applications of up to IP65 if an additional sealing of the cover bottom is provided. For detailed information, please see the HUE series. The connection diagram shifts by the height of the intermediate jaw.

| Description | ID | IP protection class |
|------------------|---------|---------------------|
| Protection cover | | |
| HUE PGN-plus 64 | 0371480 | 65 |

The HUE protective cover is not suitable for use on grippers with gripping force maintenance. An inductive monitoring of the gripper in connection with the HUE protective cover is not possible. SCHUNK recommends the use of magnetic sensors that are approved for the respective gripper variant.

BSWS jaw quick-change jaw systems



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | | |
|---|-------------------------------------|-------------------|--|--|--|
| Jaw quick-change system ada | law quick-change system adapter pin | | | | |
| BSWS-A 64 | 0303022 | 2 | | | |
| BSWS-AR 64 | 0300092 | 2 | | | |
| Quick-change jaw system base | 2 | | | | |
| BSWS-B 64 | 0303023 | 1 | | | |
| Jaw quick-change system finger blank | | | | | |
| BSWS-ABR-PGZN-plus 64 | 0300072 | 1 | | | |
| BSWS-SBR-PGZN-plus 64 | 0300082 | 1 | | | |
| Jaw quick-change system locking mechanism | | | | | |
| BSWS-UR 64 | 0302991 | 1 | | | |
| | | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------|-------------|--|
| PGN-plus-P | 64 | -1 (6 bar) | | |
| PGN-plus-P | 64 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 64 | -2 (6 bar) | | |
| PGN-plus-P | 64 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-M



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.


| Description | ID | Scope of delivery | | |
|---|---------|-------------------|--|--|
| Jaw quick-change system adapter pin | | | | |
| BSWS-A 64 | 0303022 | 2 | | |
| BSWS-AR 64 | 0300092 | 2 | | |
| Quick-change jaw system base | | | | |
| BSWS-BM 64 | 1313900 | 1 | | |
| Jaw quick-change system finger blank | | | | |
| BSWS-ABRM-PGZN-plus 64 | 1420851 | 1 | | |
| Jaw quick-change system locking mechanism | | | | |
| BSWS-URM 64 | 1398401 | 1 | | |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------|-------------|--|
| PGN-plus-P | 64 | -1 (6 bar) | | |
| PGN-plus-P | 64 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 64 | -2 (6 bar) | | |
| PGN-plus-P | 64 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

Jaw quick-change system BSWS-R



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| ID | Scope of delivery | | | | |
|-------------------------------------|--|--|--|--|--|
| law quick-change system adapter pin | | | | | |
| 0300092 | 2 | | | | |
| 9 | | | | | |
| 1555914 | 1 | | | | |
| | | | | | |
| 1555950 | 1 | | | | |
| Attachment kit for proximity switch | | | | | |
| 1561455 | 1 | | | | |
| Inductive proximity switch | | | | | |
| 0301574 | | | | | |
| 0301474 | | | | | |
| 0301555 | | | | | |
| | pter pin 0300092 2 1555914 1555950 witch 1561455 0301574 0301474 | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------|-------------|--|
| PGN-plus-P | 64 | -1 (6 bar) | | |
| PGN-plus-P | 64 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 64 | -2 (6 bar) | | |
| PGN-plus-P | 64 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

ZBA-L-plus 64 intermediate jaws



- (2) Finger connection
- (56) Included in the scope of delivery
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- (81) Not included in the scope of delivery


The optional ZBA-L-plus intermediate jaws allow the screw connection diagram of the top jaws to be rotated by 90°. This makes it easier to design and produce top jaws (particularly for long versions) because no deep through-bores are required.

| Description | ID | Material | Finger interface | Scope of delivery |
|------------------|---------|----------|---------------------|-------------------|
| Intermediate jaw | | | | |
| ZBA-L-plus 64 | 0311722 | Aluminum | PGN-plus 64 | 1 |

PGN-plus-P 64

Universal gripper

UZB 64 universal intermediate jaw



- 1 Gripper connection
- 2 Finger connection
- (54) Optional right or left connection
- 57 Locking
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The drawing shows the UZB universal intermediate jaw.

| Description | ID | Grid dimension |
|------------------------|---------|----------------|
| | | [mm] |
| Universal intermediate | jaw | |
| UZB 64 | 0300042 | 1.5 |
| Finger blank | | |
| ABR-PGZN-plus 64 | 0300010 | |
| SBR-PGZN-plus 64 | 0300020 | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|------------|--|-------------|--|
| PGN-plus-P | 64 | -1 (6 bar) | | |
| PGN-plus-P | 64 | -1-AS/1-IS (6 bar | | |
| PGN-plus-P | 64 | -2 (6 bar) | | |
| PGN-plus-P | 64 | -2-AS/2-IS (6 bar |) 0000 | |
| Legend | | | | |
| | Can be co | Can be combined without restrictions | | |
| | Use with r | Use with restrictions (see loading limits) | | |
| 0000 | cannot be | cannot be combined | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Finger blanks ABR/SBR-PGZN-plus 64




- (2) Finger connection
- 72 Fit for centering sleeves

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 64 | 0300010 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 64 | 0300020 | Steel (1.7131) | 1 |

When finger blanks are used, the closing stroke of individual gripper series may be limited. Please check this in detail in advance using the CAD data and adjust the reworking of the fingers accordingly.

Tolerance compensation unit TCU




90 Monitoring of locking

Grippers can be directly mounted without an adapter plate. Tolerance compensation unit and gripper have an identical screw connection diagram. Therefore the tolerance compensation units can be assembled later. Please consider the additional assembly height of the tolerance compensation unit. For details please refer to our catalog robot accessories.

| Description | ID | Locking | Deflection | Often combined |
|-------------------|---------|---------|---------------|----------------|
| Compensation unit | | | | |
| TCU-P-064-3-MV | 0324774 | yes | ±1°/±1,5°/±2° | • |
| TCU-P-064-3-0V | 0324775 | no | ±1°/±1,5°/±2° | |

Adapter plate for PGN-plus 64




- 1 Robot-side connection
- Tool-side connection
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The adapter plate has integrated air feed-throughs in order to be able to use the hose-free direct connection of the appropriate gripper.

| Description | ID |
|-----------------|---------|
| Tool side | |
| A-CWA-080-064-P | 0305784 |

Compensation unit AGE-F




90 Monitoring

The unit has direct connection possibilities for different grippers of the PGN-plus, PGN-plus-P and PZN-plus series. For more detailed information, please refer to the main view.

| Description | ID | Compensation XY | Reset force | Often combined |
|-------------------|---------|--------------------|-------------|----------------|
| | | [mm] | [N] | |
| Compensation unit | | | | |
| AGE-F-XY-063-1 | 0324940 | ± 4 | 12 | |
| AGE-F-XY-063-2 | 0324941 | ± 4 | 16 | |
| AGE-F-XY-063-3 | 0324942 | ± 4 | 20 | • |

① Due to the interfering contour, monitoring of the gripper is not possible.

Compact change system for grippers



- 4 Grippers
- 90 CWA compact change adapter (91) CWK compact change master
- 92) A-CWA adapter plate
 - (93) CWA compact change adapter
 - (94) CWK compact change master


Grippers can be directly mounted without an adapter plate. For details see our catalog Gripping or Robot Accessories.

| Description | ID |
|--------------------|---------|
| Tool side | |
| A-CWA-080-064-P | 0305784 |
| CWA compact change | adapter |
| CWA-064-P | 0305765 |
| CWK compact change | master |
| CWK-064-P | 0305764 |

PGN-plus-P 64

Universal gripper

Modular Assembly Automation




4 Grippers

91) ASG adapter plate

90 Linear module CLM/KLM/LM/ELP/ ELM/ELS/HLM

Grippers and linear modules can be combined with standard adapter plates from the modular assembly system. For more information see our main catalog "Modular Assembly Automation".

Inductive proximity switches



17) Cable outlet

91) Sensor IN..-SA


90 Sensor IN ...

Directly mounted end position monitoring.

| · · | | |
|------------------------------------|----------------|----------------|
| Description | ID | Often combined |
| Inductive proximity switch | | |
| IN 80-S-M12 | 0301578 | |
| IN 80-2-08 NI | 0301478 | • |
| INK 80-S | 0301550 | |
| Inductive proximity switch with la | teral cable ou | tlet |
| IN 80-S-M12-SA | 0301587 | |
| IN 80-S-M8-SA | 0301483 | • |
| INK 80-S-SA | 0301566 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BG12-L 3P-0500-PNP | 30016369 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| KA BW12-L 3P-0300-PNP | 0301503 | |
| KA BW12-L 3P-0500-PNP | 0301507 | |
| Clip for connector/socket | | |
| CLI-M12 | 0301464 | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BG12-SG12 3P-0030-PNP | 0301999 | |
| KV BG12-SG12 3P-0060-PNP | 0301998 | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| KV BW12-SG12 3P-0030-PNP | 0301595 | |
| KV BW12-SG12 3P-0100-PNP | 0301596 | |
| KV BW12-SG12 3P-0200-PNP | 0301597 | |
| Sensor distributor | | |
| V2-M12 | 0301776 | • |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |
| | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Flexible position sensor



90 FPS-S sensor

92 Cable extension


(91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID |
|-------------------------|---------|
| Attachment kit for FPS | |
| AS-FPS-PGN-plus-P 64/80 | 1363890 |
| Sensor | |
| FPS-S M8 | 0301704 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Cable extension | |
| KV BG08-SG08 3P-0050 | 0301598 |
| KV BG08-SG08 3P-0100 | 0301599 |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS



17) Cable outlet

91) Sensor MMS 22...-SA


90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|-----------------------------------|-----------------|----------------|
| Electronic magnetic switch | | |
| MMS 22-S-M8-PNP | 0301032 | • |
| MMSK 22-S-PNP | 0301034 | |
| Electronic magnetic switches with | lateral cable o | outlet |
| MMS 22-S-M8-PNP-SA | 0301042 | • |
| MMSK 22-S-PNP-SA | 0301044 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| Sensor distributor | | |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |
| | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1



(17) Cable outlet

(91) Sensor MMS 22 ..-PI1-...-SA


90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | |
|---|------------------------------|----------------|--|--|--|
| Programmable magnetic switch | Programmable magnetic switch | | | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • | | | |
| MMSK 22-PI1-S-PNP | 0301162 | | | | |
| Programmable magnetic switch | with lateral c | able outlet | | | |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • | | | |
| MMSK 22-PI1-S-PNP-SA | 0301168 | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • | | | |
| MMSK 22-PI1-S-PNP-HD | 0301112 | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI2



(17) Cable outlet


90 MMS 22...-PI2-... sensor

Position monitoring with two programmable positions per sensor and electronics integrated in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | |
|---|--|----------------|--|--|--|
| Programmable magnetic switch | Programmable magnetic switch | | | | |
| MMS 22-PI2-S-M8-PNP | 0301180 | • | | | |
| MMSK 22-PI2-S-PNP | 0301182 | | | | |
| Programmable magnetic switch | Programmable magnetic switch with lateral cable outlet | | | | |
| MMS 22-PI2-S-M8-PNP-SA | 0301186 | • | | | |
| MMSK 22-PI2-S-PNP-SA | 0301188 | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | |
| MMS 22-PI2-S-M8-PNP-HD | 0301130 | • | | | |
| MMSK 22-PI2-S-PNP-HD | 0301132 | | | | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

MMS-P programmable magnetic switch




(74) Limit stop for sensor

Position monitoring with two programmable positions per sensor. End position monitoring for mounting in the C-slot.

| Description | ID | Often combined | | | |
|------------------------------|---------|----------------|--|--|--|
| Programmable magnetic switch | | | | | |
| MMSK-P 22-S-PNP | 0301371 | | | | |
| MMS-P 22-S-M8-PNP | 0301370 | • | | | |
| Connection cables | | | | | |
| KA GLN0804-LK-00500-A | 0307767 | • | | | |
| KA GLN0804-LK-01000-A | 0307768 | | | | |
| KA WLN0804-LK-00500-A | 0307765 | | | | |
| KA WLN0804-LK-01000-A | 0307766 | | | | |
| Clip for connector/socket | | | | | |
| CLI-M8 | 0301463 | | | | |
| Sensor distributor | | | | | |
| V2-M8-4P-2XM8-3P | 0301380 | | | | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

Analog position sensor MMS-A




(74) Limit stop for sensor

Non-contact measuring, analog multi-position monitoring for any number of positions, easy to assemble in the C-slot. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the chart provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-10V-M08 | 0315825 |
| MMS 22-A-10V-M12 | 0315828 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

Flexible position sensor with MMS-A




- (74) Limit stop for sensor
- (91) FPS-F5 evaluation electronic
- 90 MMS 22-A-... sensor
- 92 Connection cables

Flexible position monitoring of up to five positions. Sensor can be taught using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-05V-M08 | 0315805 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Sensor Teaching Tool | |
| MT-MMS 22-PI | 0301030 |
| Connection cables | |
| KA BG16-L 12P-1000 | 0301801 |

When using an FPS system, one MMS 22-A-05V and one evaluation electronics (FPS-F5) are required per each gripper, as well as an attachment kit (AS), if listed. On option, cable extensions (KV) are available - see catalog chapter "Accessories."

Programmable magnetic switch MMS-I0-Link




74) Limit stop for sensor

Sensor for multi-position monitoring through detection of the complete gripper stroke. The sensor is mounted directly in the C-slot of the gripper. The sensor is programmed for the gripper via the IO-Link interface, Magnet teaching tool MT (included in scope of delivery; ID 0301030) or the ST plug teaching tool (not included in scope of delivery; ID 0301026). An IO-Link master is required for operation.

| Description | ID |
|------------------|--------------|
| Programmable mag | netic switch |
| MMS 22-I0L-M08 | 0315830 |
| MMS 22-I0L-M12 | 0315835 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

APS-Z80 analog position sensor




Non-contact measuring, analog multi-position monitoring for any number of positions.

| Description | ID | Often combined |
|----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 64-1 | 1366196 | |
| AS-APS-Z80-PGN-plus-P 64-2 | 1366200 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |


When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 80-1 | PGN-plus-P 80-2 | PGN-plus-P 80-1-AS | PGN-plus-P 80-2-AS | PGN-plus-P 80-1-IS | PGN-plus-P 80-2-IS |
|------------------------------------|-------|--------------------|--------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| ID | | 0318520 | 0318521 | 0318522 | 0318523 | 0318524 | 0318525 |
| Stroke per jaw | [mm] | 8 | 4 | 8 | 4 | 8 | 4 |
| Closing/opening force | [N] | 550/610 | 1100/1220 | 760/- | 1500/- | -/850 | -/1600 |
| Min. spring force | [N] | | | 210 | 400 | 240 | 380 |
| Weight | [kg] | 0.51 | 0.51 | 0.63 | 0.63 | 0.63 | 0.63 |
| Recommended workpiece weight | [kg] | 2.75 | 5.5 | 2.75 | 5.5 | 2.75 | 5.5 |
| Cylinder volume per double stroke | [cm³] | 29 | 29 | 44 | 44 | 52 | 52 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.035/0.035 | 0.035/0.035 | 0.03/0.05 | 0.03/0.05 | 0.05/0.03 | 0.05/0.03 |
| Closing/opening time with spring | [s] | | | 0.08 | 0.08 | 0.08 | 0.08 |
| Max. permissible finger length | [mm] | 125 | 115 | 115 | 105 | 115 | 105 |
| Max. permissible weight per finger | [kg] | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 | 0.7 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 |
| Dimensions X x Y x Z | [mm] | 96 x 42 x 49 | 96 x 42 x 49 | 96 x 42 x 67 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1317561 | 1317563 | 1317564 | 1317565 | 1317568 | 1317569 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 0.58 | 0.58 | 0.7 | 0.7 | 0.7 | 0.7 |
| Corrosion-protected version | | 38318520 | 38318521 | 38318522 | 38318523 | 38318524 | 38318525 |
| High-temperature version | | 39318520 | 39318521 | 39318522 | 39318523 | 39318524 | 39318525 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 0318526 | 0318527 | 0318528 | 0318529 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- (2) Finger connection
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22..
- (91) Sensor IN ...
- (92) Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection






 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M3



The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.


Gripping force maintenance version AS/IS



10 Projection applies only for AS version

The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- (9) For mounting screw connection diagram, see basic version
- 15 Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|-------------------|---------|
| Dust cover | |
| | 4247404 |
| SAD PGN-plus-P 80 | 1347484 |

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.


Precision version



- 20 For version AS/IS
- 72 Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

SDV-P pressure maintenance valve



4 Grippers


90 SDV-P pressure maintenance

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter | | |
|---|---------|---------------------------|--|--|
| | | [mm] | | |
| Pressure maintenanc | e valve | | | |
| SDV-P 04 | 0403130 | 6 | | |
| SDV-P 07 | 0403131 | 8 | | |
| Pressure maintenance valve with air bleed screw | | | | |
| SDV-P 04-E | 0300120 | 6 | | |
| SDV-P 07-E | 0300121 | 8 | | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

SDV-P E-P pressure maintenance valve




- (3) Adapter
- 90 SDV-P E-P pressure maintenance valve
- 91) 2-finger parallel gripper PGN-plus/PGN-plus-P
- 92 2-finger parallel gripper JGP-P
- 93) 2-finger angular gripper PWG-plus
- (94) 2-finger parallel gripper PGB
- 95) Sealed DPG-plus gripper

The SDV-P E-P pressure maintenance valves ensure that the pressure in the piston chamber is maintained temporarily during an emergency stop. SDV-P E-P can be directly connected to the listed grippers without the need for additional pneumatic hoses.

| Description | ID |
|------------------|------------|
| Pressure mainten | ance valve |
| SDV-P 80-E-P | 0300125 |

Protective cover HUE PGN-plus 80




(9) For mounting screw connection diagram, see basic version

The HUE protective cover fully protects the gripper against external influences. The cover is suitable for applications of up to IP65 if an additional sealing of the cover bottom is provided. For detailed information, please see the HUE series. The connection diagram shifts by the height of the intermediate jaw.

| Description ID | | IP protection class | |
|------------------|---------|---------------------|--|
| Protection cover | | | |
| HUE PGN-plus 80 | 0371481 | 65 | |

The HUE protective cover is not suitable for use on grippers with gripping force maintenance. An inductive monitoring of the gripper in connection with the HUE protective cover is not possible. SCHUNK recommends the use of magnetic sensors that are approved for the respective gripper variant.

BSWS jaw quick-change jaw systems



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.


| Description | ID | Scope of delivery | | | | |
|---|-------------------------------------|-------------------|--|--|--|--|
| Jaw quick-change system ada | Jaw quick-change system adapter pin | | | | | |
| BSWS-A 80 | 0303024 | 2 | | | | |
| BSWS-AR 80 | 0300093 | 2 | | | | |
| Quick-change jaw system base | 9 | | | | | |
| BSWS-B 80 | 0303025 | 1 | | | | |
| Jaw quick-change system finger blank | | | | | | |
| BSWS-ABR-PGZN-plus 80 | 0300073 | 1 | | | | |
| BSWS-SBR-PGZN-plus 80 | 0300083 | 1 | | | | |
| Jaw quick-change system locking mechanism | | | | | | |
| BSWS-UR 80 | 0302992 | 1 | | | | |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | | |
|------------|------------|--|---------------------|--|--|
| PGN-plus-P | 80 | -1 (6 bar) | | | |
| PGN-plus-P | 80 | -1-AS/1-IS (6 bar | ·) | | |
| PGN-plus-P | 80 | -2 (6 bar) | | | |
| PGN-plus-P | 80 | -2-AS/2-IS (6 bar | r) | | |
| Legend | | | | | |
| | Can be cor | Can be combined without restrictions | | | |
| | Use with r | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be | cannot be combined | | | |

Jaw quick-change system BSWS-M



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery |
|---------------------------------|--------------|-------------------|
| Jaw quick-change system adapt | er pin | |
| BSWS-A 80 | 0303024 | 2 |
| BSWS-AR 80 | 0300093 | 2 |
| Quick-change jaw system base | | |
| BSWS-BM 80 | 1313901 | 1 |
| Jaw quick-change system finger | rblank | |
| BSWS-ABRM-PGZN-plus 80 | 1420852 | 1 |
| Jaw quick-change system locking | ig mechanism | |
| BSWS-URM 80 | 1398402 | 1 |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|-----------------------|-------------|
| PGN-plus-P | 80 | -1 (6 bar) | |
| PGN-plus-P | 80 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 80 | -2 (6 bar) | |
| PGN-plus-P | 80 | -2-AS/2-IS (6 bar) | |
| Legend | | | |
| | Can be combined w | ithout restrictions | |
| | Use with restriction | ns (see loading limit | s) |
| 0000 | cannot be combine | d | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-R



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.


| Description | ID | Scope of delivery |
|---------------------------------|---------|-------------------|
| Jaw quick-change system adap | ter pin | |
| BSWS-AR 80 | 0300093 | 2 |
| Quick-change jaw system base | | |
| BSWS-BR 80 | 1555917 | 1 |
| Storage system | | |
| BSWS-SR 80 | 1555951 | 1 |
| Attachment kit for proximity sw | vitch | |
| AS-IN40-BSWS-SR 80/100 | 1561458 | 1 |
| Inductive proximity switch | | |
| IN 40-S-M12 | 0301574 | |
| IN 40-S-M8 | 0301474 | |
| INK 40-S | 0301555 | |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|------------------------|-------------|
| PGN-plus-P | 80 | -1 (6 bar) | |
| PGN-plus-P | 80 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 80 | -2 (6 bar) | |
| PGN-plus-P | 80 | -2-AS/2-IS (6 bar) | |
| Legend | | | |
| | Can be combined | without restrictions | |
| | Use with restriction | ons (see loading limit | s) |
| 0000 | cannot be combin | ed | |

ZBA-L-plus 80 intermediate jaws




- 2 Finger connection
- (56) Included in the scope of delivery
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 81) Not included in the scope of delivery

The optional ZBA-L-plus intermediate jaws allow the screw connection diagram of the top jaws to be rotated by 90°. This makes it easier to design and produce top jaws (particularly for long versions) because no deep through-bores are required.

| Description | ID | Material | Finger interface | Scope of delivery |
|------------------|---------|----------|---------------------|-------------------|
| Intermediate jaw | | | | |
| ZBA-L-plus 80 | 0311732 | Aluminum | PGN-plus 80 | 1 |

UZB 80 universal intermediate jaw



- 1 Gripper connection
- (2) Finger connection
- 54 Optional right or left connection
- 57 Locking
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The drawing shows the UZB universal intermediate jaw. The fully removable UZB-S slide (can also be ordered separately) allows for a quick jaw change.


| Description | ID | Grid dimension |
|--------------------------|--------------|----------------|
| | | [mm] |
| Universal intermediate | jaw | |
| UZB 80 | 0300043 | 2 |
| Finger blank | | |
| ABR-PGZN-plus 80 | 0300011 | |
| SBR-PGZN-plus 80 | 0300021 | |
| Slide for universal inte | rmediate jaw | |
| UZB-S 80 | 5518271 | 2 |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|-----------------------|-------------|
| PGN-plus-P | 80 | -1 (6 bar) | |
| PGN-plus-P | 80 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 80 | -2 (6 bar) | |
| PGN-plus-P | 80 | -2-AS/2-IS (6 bar) | 0000 |
| Legend | | | |
| | Can be combined w | ithout restrictions | |
| | Use with restriction | ns (see loading limit | s) |
| 0000 | cannot be combine | d | |

Finger blanks ABR/SBR-PGZN-plus 80




- (2) Finger connection
- 90 ABR-PGZN-plus
- (72) Fit for centering sleeves
- 91) SBR-PGZN-plus

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 80 | 0300011 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 80 | 0300021 | Steel (1.7131) | 1 |

When finger blanks are used, the closing stroke of individual gripper series may be limited. Please check this in detail in advance using the CAD data and adjust the reworking of the fingers accordingly.

Compensation unit AGE-F




90 Monitoring

The unit has direct connection possibilities for different grippers of the PGN-plus, PGN-plus-P and PZN-plus series. For more detailed information, please refer to the main view.

| Description | ID | Compensation XY | Reset force | Often combined |
|-------------------|---------|--------------------|-------------|----------------|
| | | [mm] | [N] | |
| Compensation unit | | | | |
| AGE-F-XY-063-1 | 0324940 | ± 4 | 12 | |
| AGE-F-XY-063-2 | 0324941 | ± 4 | 16 | |
| AGE-F-XY-063-3 | 0324942 | ± 4 | 20 | • |

① Due to the interfering contour, monitoring of the gripper is not possible.

Tolerance compensation unit TCU




90 Monitoring of locking

Grippers can be directly mounted without an adapter plate. Tolerance compensation unit and gripper have an identical screw connection diagram. Therefore the tolerance compensation units can be assembled later. Please consider the additional assembly height of the tolerance compensation unit. For details please refer to our catalog robot accessories.

| Description | ID | Locking | Deflection | Often combined |
|-------------------|---------|---------|---------------|-------------------|
| Compensation unit | | | | |
| TCU-P-080-3-MV | 0324792 | yes | ±1°/±1,5°/±2° | • |
| TCU-P-080-3-0V | 0324793 | no | ±1°/±1.5°/±2° | |

Adapter plate PGN-plus 80




- (1) Robot-side connection
- **72** Fit for centering sleeves
- 2 Tool-side connection
- 80 Depth of the centering sleeve hole in the counter part

The adapter plate has integrated air feed-throughs in order to be able to use the hose-free direct connection of the appropriate gripper.

| Description | ID | |
|-----------------|---------|--|
| Tool side | | |
| A-CWA-100-080-P | 0305804 | |

Compact change system for grippers




- 4 Grippers
- **92** A-CWA adapter plate
- 90 CWA compact change adapter
- (93) CWA compact change adapter
- (91) CWK compact change master
- (94) CWK compact change master

Grippers can be directly mounted without an adapter plate. For details see our catalog Gripping or Robot Accessories.

| Description | ID |
|--------------------|---------|
| Tool side | |
| A-CWA-100-080-P | 0305804 |
| CWA compact change | adapter |
| CWA-080-P | 0305781 |
| CWK compact change | master |
| CWK-080-P | 0305780 |


Modular Assembly Automation



- 4 Grippers
- (91) ASG adapter plate
- 90 Linear module CLM/KLM/LM/ELP/ ELM/ELS/HLM

Grippers and linear modules can be combined with standard adapter plates from the modular assembly system. For more information see our main catalog "Modular Assembly Automation".

Inductive proximity switches




- (17) Cable outlet
- 91) Sensor IN..-SA
- 90 Sensor IN ...

Directly mounted end position monitoring.

| Inductive proximity switch IN 80-S-M12 0301578 IN 80-S-M8 0301478 ● INK 80-S 0301550 Inductive proximity switch with lateral cable outlet IN 80-S-M12-SA 0301587 IN 80-S-M8-SA 0301483 ● INK 80-S-M8-SA 0301566 Connection cables KA BG08-L 3P-0300-PNP 0301622 ● KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 03016369 KA BW08-L 3P-0500-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW08-L 3P-0500-PNP 0301503 KA BW12-L 3P-0500-PNP 0301503 KA BW12-L 3P-0500-PNP 0301507 | |
|---|--|
| IN 80-S-M8 INK 80-S Inductive proximity switch with lateral cable outlet IN 80-S-M12-SA IN 80-S-M8-SA INK 80-S-M8-SA INK 80-S-SA Connection cables KA BG08-L 3P-0300-PNP KA BG08-L 3P-0500-PNP MA BG12-L 3P-0500-PNP MA BW08-L 3P-0300-PNP MA BW08-L 3P-0500-PNP MA BW08-L 3P-0300-PNP MA BW12-L 3P-0300-PNP | |
| INK 80-S Inductive proximity switch with lateral cable outlet IN 80-S-M12-SA IN 80-S-M8-SA INK 80-S-SA INK 80-S-S | |
| Inductive proximity switch with lateral cable outlet IN 80-S-M12-SA 0301587 IN 80-S-M8-SA 0301483 ● INK 80-S-SA 0301566 Connection cables KA BG08-L 3P-0300-PNP 0301622 ● KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 03016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW08-L 3P-0300-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| IN 80-S-M12-SA 0301587 IN 80-S-M8-SA 0301483 INK 80-S-SA 0301566 Connection cables KA BG08-L 3P-0300-PNP 0301622 KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 0301594 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| IN 80-S-M8-SA 0301483 | |
| INK 80-S-SA 0301566 Connection cables KA BG08-L 3P-0300-PNP 0301622 KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| Connection cables KA BG08-L 3P-0300-PNP 0301622 KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BG08-L 3P-0300-PNP 0301622 KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BW12-L 3P-0300-PNP 0301503 | |
| | |
| KA BW12-L 3P-0500-PNP 0301507 | |
| | |
| Clip for connector/socket | |
| CLI-M12 0301464 | |
| CLI-M8 0301463 | |
| Cable extension | |
| KV BG12-SG12 3P-0030-PNP 0301999 | |
| KV BG12-SG12 3P-0060-PNP 0301998 | |
| KV BW08-SG08 3P-0030-PNP 0301495 | |
| KV BW08-SG08 3P-0100-PNP 0301496 | |
| KV BW08-SG08 3P-0200-PNP 0301497 | |
| KV BW12-SG12 3P-0030-PNP 0301595 | |
| KV BW12-SG12 3P-0100-PNP 0301596 | |
| KV BW12-SG12 3P-0200-PNP 0301597 | |
| Sensor distributor | |
| V2-M12 0301776 • | |
| V2-M8 0301775 • | |
| V4-M8 0301746 | |
| V8-M8 0301751 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Flexible position sensor




- 90 FPS-S sensor
- 92 Cable extension
- 91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID |
|-------------------------|---------|
| Attachment kit for FPS | |
| AS-FPS-PGN-plus-P 64/80 | 1363890 |
| Sensor | |
| FPS-S M8 | 0301704 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Cable extension | |
| KV BG08-SG08 3P-0050 | 0301598 |
| KV BG08-SG08 3P-0100 | 0301599 |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS




- (17) Cable outlet
- 91) Sensor MMS 22...-SA
- 90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|-----------------------------------|-----------------|----------------|
| Electronic magnetic switch | | |
| MMS 22-S-M8-PNP | 0301032 | • |
| MMSK 22-S-PNP | 0301034 | |
| Electronic magnetic switches with | lateral cable (| outlet |
| MMS 22-S-M8-PNP-SA | 0301042 | • |
| MMSK 22-S-PNP-SA | 0301044 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| Sensor distributor | | |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1




- (17) Cable outlet
- **91** Sensor MMS 22 ..-PI1-...-SA
- 90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| 0 11 | | 0 |
|------------------------------|----------------|-----------------|
| Description | ID | Often combined |
| Programmable magnetic switch | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • |
| MMSK 22-PI1-S-PNP | 0301162 | |
| Programmable magnetic switch | with lateral c | able outlet |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • |
| MMSK 22-PI1-S-PNP-SA | 0301168 | |
| Programmable magnetic switch | with stainles | s steel housing |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • |
| MMSK 22-PI1-S-PNP-HD | 0301112 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI2



(17) Cable outlet


90 MMS 22...-PI2-... sensor

Position monitoring with two programmable positions per sensor and electronics integrated in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined |
|------------------------------|----------------|-----------------|
| Programmable magnetic switch | | |
| MMS 22-PI2-S-M8-PNP | 0301180 | • |
| MMSK 22-PI2-S-PNP | 0301182 | |
| Programmable magnetic switch | with lateral c | able outlet |
| MMS 22-PI2-S-M8-PNP-SA | 0301186 | • |
| MMSK 22-PI2-S-PNP-SA | 0301188 | |
| Programmable magnetic switch | with stainless | s steel housing |
| MMS 22-PI2-S-M8-PNP-HD | 0301130 | • |
| MMSK 22-PI2-S-PNP-HD | 0301132 | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

MMS-P programmable magnetic switch




(74) Limit stop for sensor

Position monitoring with two programmable positions per sensor. End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|------------------------------|---------|----------------|
| Programmable magnetic switch | h | |
| MMSK-P 22-S-PNP | 0301371 | |
| MMS-P 22-S-M8-PNP | 0301370 | • |
| Connection cables | | |
| KA GLN0804-LK-00500-A | 0307767 | • |
| KA GLN0804-LK-01000-A | 0307768 | |
| KA WLN0804-LK-00500-A | 0307765 | |
| KA WLN0804-LK-01000-A | 0307766 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Sensor distributor | | |
| V2-M8-4P-2XM8-3P | 0301380 | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

Analog position sensor MMS-A




(74) Limit stop for sensor

Non-contact measuring, analog multi-position monitoring for any number of positions, easy to assemble in the C-slot. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the chart provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-10V-M08 | 0315825 |
| MMS 22-A-10V-M12 | 0315828 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

Flexible position sensor with MMS-A




- 74) Limit stop for sensor
- (91) FPS-F5 evaluation electronic
- 90 MMS 22-A-... sensor
- (92) Connection cables

Flexible position monitoring of up to five positions. Sensor can be taught using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-05V-M08 | 0315805 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Sensor Teaching Tool | |
| MT-MMS 22-PI | 0301030 |
| Connection cables | |
| KA BG16-L 12P-1000 | 0301801 |

When using an FPS system, one MMS 22-A-05V and one evaluation electronics (FPS-F5) are required per each gripper, as well as an attachment kit (AS), if listed. On option, cable extensions (KV) are available - see catalog chapter "Accessories."

Programmable magnetic switch MMS-I0-Link




(74) Limit stop for sensor

Sensor for multi-position monitoring through detection of the complete gripper stroke. The sensor is mounted directly in the C-slot of the gripper. The sensor is programmed for the gripper via the IO-Link interface, Magnet teaching tool MT (included in scope of delivery; ID 0301030) or the ST plug teaching tool (not included in scope of delivery; ID 0301026). An IO-Link master is required for operation.

| Description | ID |
|------------------|--------------|
| Programmable mag | netic switch |
| MMS 22-I0L-M08 | 0315830 |
| MMS 22-I0L-M12 | 0315835 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

APS-Z80 analog position sensor



Non-contact measuring, analog multi-position monitoring for any number of positions.


| Description | ID | Often combined |
|----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 80-1 | 1366209 | |
| AS-APS-Z80-PGN-plus-P 80-2 | 1366215 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |

When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.


Universal gripper




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 100-1 | PGN-plus-P 100-2 | PGN-plus-P 100-1-AS | PGN-plus-P 100-2-AS | PGN-plus-P 100-1-IS | PGN-plus-P 100-2-IS |
|------------------------------------|-------|---------------------|---------------------|------------------------|------------------------|------------------------|------------------------|
| ID | | 0318544 | 0318545 | 0318546 | 0318547 | 0318548 | 0318549 |
| Stroke per jaw | [mm] | 10 | 5 | 10 | 5 | 10 | 5 |
| Closing/opening force | [N] | 870/930 | 1750/1870 | 1180/- | 2200/- | -/1250 | -/2400 |
| Min. spring force | [N] | | | 310 | 450 | 320 | 530 |
| Weight | [kg] | 0.9 | 0.9 | 1.1 | 1.1 | 1.1 | 1.1 |
| Recommended workpiece weight | [kg] | 4.35 | 8.75 | 4.35 | 8.75 | 4.35 | 8.75 |
| Cylinder volume per double stroke | [cm³] | 55 | 55 | 84 | 84 | 92 | 92 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.06/0.06 | 0.06/0.06 | 0.05/0.09 | 0.05/0.09 | 0.09/0.05 | 0.09/0.05 |
| Closing/opening time with spring | [s] | | | 0.10 | 0.10 | 0.10 | 0.10 |
| Max. permissible finger length | [mm] | 160 | 145 | 145 | 130 | 145 | 130 |
| Max. permissible weight per finger | [kg] | 1.3 | 1.3 | 1.3 | 1.3 | 1.3 | 1.3 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 |
| Dimensions X x Y x Z | [mm] | 120 x 50 x 55 | 120 x 50 x 55 | 120 x 50 x 81 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1317570 | 1317571 | 1317572 | 1317574 | 1317578 | 1317581 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 1.02 | 1.02 | 1.22 | 1.22 | 1.22 | 1.22 |
| Corrosion-protected version | | 38318544 | 38318545 | 38318546 | 38318547 | 38318548 | 38318549 |
| High-temperature version | | 39318544 | 39318545 | 39318546 | 39318547 | 39318548 | 39318549 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 0318550 | 0318551 | 0318552 | 0318553 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- (2) Finger connection
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22..
- (91) Sensor IN ...
- ©2 Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection






 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M3



The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.


Gripping force maintenance version AS/IS



10 Projection applies only for AS version

The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- (9) For mounting screw connection diagram, see basic version
- 15 Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|--------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 100 | 1347566 |

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.


Precision version



- 20 For version AS/IS
- 72 Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

SDV-P pressure maintenance valve



4 Grippers


90 SDV-P pressure maintenance

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter | | |
|---|---------|---------------------------|--|--|
| | | [mm] | | |
| Pressure maintenance valve | | | | |
| SDV-P 04 | 0403130 | 6 | | |
| SDV-P 07 | 0403131 | 8 | | |
| Pressure maintenance valve with air bleed screw | | | | |
| SDV-P 04-E | 0300120 | 6 | | |
| SDV-P 07-E | 0300121 | 8 | | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

SDV-P E-P pressure maintenance valve




- (3) Adapter
- 90 SDV-P E-P pressure maintenance valve
- 91) 2-finger parallel gripper PGN-plus/PGN-plus-P
- 92 2-finger parallel gripper JGP-P
- 93 2-finger angular gripper PWG-plus
- (94) 2-finger parallel gripper PGB
- 95) Sealed DPG-plus gripper

The SDV-P E-P pressure maintenance valves ensure that the pressure in the piston chamber is maintained temporarily during an emergency stop. SDV-P E-P can be directly connected to the listed grippers without the need for additional pneumatic hoses.

| Description | ID |
|-------------------|------------|
| Pressure maintena | ince valve |
| SDV-P 100-E-P | 0300126 |

Pneumatic positioning device PPD




The PPD allows flexibility in all applications with pneumatic grippers through free positioning, gripping force and speed adjustment.

| Description | ID | | |
|---|---------|--|--|
| Pneumatic positioning device | | | |
| PPD 20-IOL | 1540700 | | |
| Adapter | | | |
| A GGN0804-1204-A | 1540691 | | |
| 10-Link connection cable | | | |
| KA GGN1205-1212-IOL-00100-A | 1540697 | | |
| Voltage supply connection cable - cable track compa | | | |
| KA GLN12B05-LK-01000-A | 1540660 | | |
| Cable extension | | | |
| KV GGN0804-I0-00150-A | 1540662 | | |
| KV GGN0804-10-00300-A | 1540663 | | |
| Assembly set | | | |
| Assembly set PPD | 1540705 | | |

① In addition to the PPD, a position sensor (SCHUNK IO-Link sensor or analog sensor (4...20 mA)) is required.

Protective cover HUE PGN-plus 100




9 For mounting screw connection diagram, see basic version

The HUE protective cover fully protects the gripper against external influences. The cover is suitable for applications of up to IP65 if an additional sealing of the cover bottom is provided. For detailed information, please see the HUE series. The connection diagram shifts by the height of the intermediate jaw.

| Description ID | | IP protection class | |
|------------------|---------|---------------------|--|
| Protection cover | | | |
| HUE PGN-plus 100 | 0371482 | 65 | |

The HUE protective cover is not suitable for use on grippers with gripping force maintenance. An inductive monitoring of the gripper in connection with the HUE protective cover is not possible. SCHUNK recommends the use of magnetic sensors that are approved for the respective gripper variant.

BSWS jaw quick-change jaw systems



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | |
|---|---------|-------------------|--|
| Jaw quick-change system adapter pin | | | |
| BSWS-A 100 | 0303026 | 2 | |
| BSWS-AR 100 | 0300094 | 2 | |
| Quick-change jaw system base | | | |
| BSWS-B 100 | 0303027 | 1 | |
| Jaw quick-change system finger blank | | | |
| BSWS-ABR-PGZN-plus 100 | 0300074 | 1 | |
| BSWS-SBR-PGZN-plus 100 | 0300084 | 1 | |
| Jaw quick-change system locking mechanism | | | |
| BSWS-UR 100 | 0302993 | 1 | |
| | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------|-------------|--|
| PGN-plus-P | 100 | -1 (6 bar) | | |
| PGN-plus-P | 100 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 100 | -2 (6 bar) | | |
| PGN-plus-P | 100 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-M



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.


| Description | ID | Scope of delivery | | |
|---|---------|-------------------|--|--|
| Jaw quick-change system adapter pin | | | | |
| BSWS-A 100 | 0303026 | 2 | | |
| BSWS-AR 100 | 0300094 | 2 | | |
| Quick-change jaw system base | | | | |
| BSWS-BM 100 | 1313902 | 1 | | |
| Jaw quick-change system finger blank | | | | |
| BSWS-ABRM-PGZN-plus 100 | 1420853 | 1 | | |
| Jaw quick-change system locking mechanism | | | | |
| BSWS-URM 100 | 1398403 | 1 | | |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------|-------------|--|
| PGN-plus-P | 100 | -1 (6 bar) | | |
| PGN-plus-P | 100 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 100 | -2 (6 bar) | | |
| PGN-plus-P | 100 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

Jaw quick-change system BSWS-R



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| actuned information, preuse | refer to the | corresponding product. |
|---------------------------------|--------------|------------------------|
| Description | ID | Scope of delivery |
| Jaw quick-change system adapt | ter pin | |
| BSWS-AR 100 | 0300094 | 2 |
| Quick-change jaw system base | | |
| BSWS-BR 100 | 1555933 | 1 |
| Storage system | | |
| BSWS-SR 100 | 1555959 | 1 |
| Attachment kit for proximity sw | vitch | |
| AS-IN40-BSWS-SR 80/100 | 1561458 | 1 |
| Inductive proximity switch | | |
| IN 40-S-M12 | 0301574 | |
| IN 40-S-M8 | 0301474 | |
| INK 40-S | 0301555 | |
| | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|-----------------------|-------------|
| PGN-plus-P | 100 | -1 (6 bar) | |
| PGN-plus-P | 100 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 100 | -2 (6 bar) | |
| PGN-plus-P | 100 | -2-AS/2-IS (6 bar) | |
| Legend | | | |
| | Can be combined w | ithout restrictions | |
| | Use with restriction | ns (see loading limit | s) |
| 0000 | cannot be combine | d | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

ZBA-L-plus 100 intermediate jaws



- (2) Finger connection
- (56) Included in the scope of delivery
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 81) Not included in the scope of delivery


The optional ZBA-L-plus intermediate jaws allow the screw connection diagram of the top jaws to be rotated by 90°. This makes it easier to design and produce top jaws (particularly for long versions) because no deep through-bores are required.

| Description | ID | Material | Finger interface | Scope of delivery |
|------------------|---------|----------|---------------------|-------------------|
| Intermediate jaw | | | | |
| ZBA-L-plus 100 | 0311742 | Aluminum | PGN-plus 100 | 1 |

PGN-plus-P 100

Universal gripper

UZB 100 universal intermediate jaw



- 1 Gripper connection
- 2 Finger connection
- (54) Optional right or left connection
- 57 Locking
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The drawing shows the UZB universal intermediate jaw. The fully removable UZB-S slide (can also be ordered separately) allows for a quick jaw change.

| Description | ID | Grid dimension |
|----------------------------|-------------|----------------|
| | | [mm] |
| Universal intermediate j | aw | |
| UZB 100 | 0300044 | 2.5 |
| Finger blank | | |
| ABR-PGZN-plus 100 | 0300012 | |
| SBR-PGZN-plus 100 | 0300022 | |
| Slide for universal intern | mediate jaw | |
| UZB-S 100 | 5518272 | 2.5 |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|-----------------------|-------------|
| PGN-plus-P | 100 | -1 (6 bar) | |
| PGN-plus-P | 100 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 100 | -2 (6 bar) | |
| PGN-plus-P | 100 | -2-AS/2-IS (6 bar) | 0000 |
| Legend | | | |
| | Can be combined w | vithout restrictions | |
| | Use with restriction | ns (see loading limit | s) |
| 0000 | cannot be combine | d | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Finger blanks ABR/SBR-PGZN-plus 100



(2) Finger connection


72) Fit for centering sleeves

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|-------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 100 | 0300012 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 100 | 0300022 | Steel (1.7131) | 1 |

When finger blanks are used, the closing stroke of individual gripper series may be limited. Please check this in detail in advance using the CAD data and adjust the reworking of the fingers accordingly.

Tolerance compensation unit TCU




90 Monitoring of locking

Grippers can be directly mounted without an adapter plate. Tolerance compensation unit and gripper have an identical screw connection diagram. Therefore the tolerance compensation units can be assembled later. Please consider the additional assembly height of the tolerance compensation unit. For details please refer to our catalog robot accessories.

| Description | ID | Locking | Deflection | Often combined |
|-------------------|---------|---------|-----------------|----------------|
| Compensation unit | | | | |
| TCU-P-100-2-MV | 0324808 | yes | ±1°/±1,5°/±1,2° | • |
| TCU-P-100-3-0V | 0324811 | no | ±1°/±1,5°/±1,2° | |

Adapter plate for PGN-plus 100




- 1 Robot-side connection
- 2 Tool-side connection
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The adapter plate has integrated air feed-throughs in order to be able to use the hose-free direct connection of the appropriate gripper.

| Description | ID |
|-----------------|---------|
| Tool side | |
| A-CWA-125-100-P | 0305829 |

Compensation unit AGE-F




90 Monitoring

The unit has direct connection possibilities for different grippers of the PGN-plus, PGN-plus-P and PZN-plus series. For more detailed information, please refer to the main view.

| Description | ID | Compensation XY | Reset force | Often combined |
|-------------------|---------|--------------------|-------------|----------------|
| | | [mm] | [N] | |
| Compensation unit | | | | |
| AGE-F-XY-080-1 | 0324960 | ± 5 | 39 | |
| AGE-F-XY-080-2 | 0324961 | ± 5 | 85 | |
| AGE-F-XY-080-3 | 0324962 | ± 5 | 90 | • |

① Due to the interfering contour, monitoring of the gripper is not possible.

Compact change system for grippers



- 4 Grippers
- (90) CWA compact change adapter
 - adapter
- 92 A-CWA adapter plate93 CWA compact change adapter
- (91) CWK compact change master
- **94** CWK compact change master


Grippers can be directly mounted without an adapter plate. For details see our catalog Gripping or Robot Accessories.

| Description | ID |
|--------------------|---------|
| Tool side | |
| A-CWA-125-100-P | 0305829 |
| CWA compact change | adapter |
| CWA-100-P | 0305801 |
| CWK compact change | master |
| CWK-100-P | 0305800 |

PGN-plus-P 100

Universal gripper

Modular Assembly Automation




4 Grippers

91) ASG adapter plate

90 Linear module CLM/KLM/LM/ELP/ ELM/ELS/HLM

Grippers and linear modules can be combined with standard adapter plates from the modular assembly system. For more information see our main catalog "Modular Assembly Automation".

Inductive proximity switches



17) Cable outlet

91) Sensor IN..-SA


90 Sensor IN ...

Directly mounted end position monitoring.

| Description | ID | Often combined |
|------------------------------------|----------------|----------------|
| Inductive proximity switch | | |
| IN 80-S-M12 | 0301578 | |
| IN 80-S-M8 | 0301478 | • |
| INK 80-S | 0301550 | |
| Inductive proximity switch with la | teral cable ou | tlet |
| IN 80-S-M12-SA | 0301587 | |
| IN 80-S-M8-SA | 0301483 | • |
| INK 80-S-SA | 0301566 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BG12-L 3P-0500-PNP | 30016369 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| KA BW12-L 3P-0300-PNP | 0301503 | |
| KA BW12-L 3P-0500-PNP | 0301507 | |
| Clip for connector/socket | | |
| CLI-M12 | 0301464 | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BG12-SG12 3P-0030-PNP | 0301999 | |
| KV BG12-SG12 3P-0060-PNP | 0301998 | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| KV BW12-SG12 3P-0030-PNP | 0301595 | |
| KV BW12-SG12 3P-0100-PNP | 0301596 | |
| KV BW12-SG12 3P-0200-PNP | 0301597 | |
| Sensor distributor | | |
| V2-M12 | 0301776 | • |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |
| | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Flexible position sensor



90 FPS-S sensor

92 Cable extension


(91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID |
|------------------------|---------|
| Attachment kit for FPS | |
| AS-FPS-PGN-plus-P 100 | 1363897 |
| Sensor | |
| FPS-S M8 | 0301704 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Cable extension | |
| KV BG08-SG08 3P-0050 | 0301598 |
| KV BG08-SG08 3P-0100 | 0301599 |
| | |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS



17) Cable outlet

91) Sensor MMS 22...-SA


90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|-----------------------------------|-----------------|----------------|
| Electronic magnetic switch | | |
| MMS 22-S-M8-PNP | 0301032 | • |
| MMSK 22-S-PNP | 0301034 | |
| Electronic magnetic switches with | lateral cable o | outlet |
| MMS 22-S-M8-PNP-SA | 0301042 | • |
| MMSK 22-S-PNP-SA | 0301044 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| Sensor distributor | | |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |
| | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1



(17) Cable outlet

(91) Sensor MMS 22 ..-PI1-...-SA


90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined |
|------------------------------|----------------|-----------------|
| Programmable magnetic switch | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • |
| MMSK 22-PI1-S-PNP | 0301162 | |
| Programmable magnetic switch | with lateral c | able outlet |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • |
| MMSK 22-PI1-S-PNP-SA | 0301168 | |
| Programmable magnetic switch | with stainless | s steel housing |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • |
| MMSK 22-PI1-S-PNP-HD | 0301112 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI2



(17) Cable outlet


90 MMS 22...-PI2-... sensor

Position monitoring with two programmable positions per sensor and electronics integrated in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined |
|------------------------------|----------------|-----------------|
| Programmable magnetic switch | | |
| MMS 22-PI2-S-M8-PNP | 0301180 | • |
| MMSK 22-PI2-S-PNP | 0301182 | |
| Programmable magnetic switch | with lateral c | able outlet |
| MMS 22-PI2-S-M8-PNP-SA | 0301186 | • |
| MMSK 22-PI2-S-PNP-SA | 0301188 | |
| Programmable magnetic switch | with stainles | s steel housing |
| MMS 22-PI2-S-M8-PNP-HD | 0301130 | • |
| MMSK 22-PI2-S-PNP-HD | 0301132 | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

MMS-P programmable magnetic switch




(74) Limit stop for sensor

Position monitoring with two programmable positions per sensor. End position monitoring for mounting in the C-slot.

| | _ | |
|------------------------------|---------|----------------|
| Description | ID | Often combined |
| Programmable magnetic switch | :h | |
| MMSK-P 22-S-PNP | 0301371 | |
| MMS-P 22-S-M8-PNP | 0301370 | • |
| Connection cables | | |
| KA GLN0804-LK-00500-A | 0307767 | • |
| KA GLN0804-LK-01000-A | 0307768 | |
| KA WLN0804-LK-00500-A | 0307765 | |
| KA WLN0804-LK-01000-A | 0307766 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Sensor distributor | | |
| V2-M8-4P-2XM8-3P | 0301380 | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

Analog position sensor MMS-A



(74) Limit stop for sensor

Non-contact measuring, analog multi-position monitoring for any number of positions, easy to assemble in the C-slot. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the chart provided, teaching is only possible with the ST teaching tools.


| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-10V-M08 | 0315825 |
| MMS 22-A-10V-M12 | 0315828 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

PGN-plus-P 100

Universal gripper

Flexible position sensor with MMS-A




- (74) Limit stop for sensor
- (91) FPS-F5 evaluation electronic
- 90 MMS 22-A-... sensor
- (92) Connection cables

Flexible position monitoring of up to five positions. Sensor can be taught using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-05V-M08 | 0315805 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Sensor Teaching Tool | |
| MT-MMS 22-PI | 0301030 |
| Connection cables | |
| KA BG16-L 12P-1000 | 0301801 |

When using an FPS system, one MMS 22-A-05V and one evaluation electronics (FPS-F5) are required per each gripper, as well as an attachment kit (AS), if listed. On option, cable extensions (KV) are available - see catalog chapter "Accessories."

Programmable magnetic switch MMS-I0-Link




74) Limit stop for sensor

Sensor for multi-position monitoring through detection of the complete gripper stroke. The sensor is mounted directly in the C-slot of the gripper. The sensor is programmed for the gripper via the IO-Link interface, Magnet teaching tool MT (included in scope of delivery; ID 0301030) or the ST plug teaching tool (not included in scope of delivery; ID 0301026). An IO-Link master is required for operation.

| Description | ID |
|------------------|--------------|
| Programmable mag | netic switch |
| MMS 22-I0L-M08 | 0315830 |
| MMS 22-I0L-M12 | 0315835 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

APS-Z80 analog position sensor




Non-contact measuring, analog multi-position monitoring for any number of positions.

| Description | ID | Often combined |
|-----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 100-1 | 1366219 | |
| AS-APS-Z80-PGN-plus-P 100-2 | 1366224 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |


When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 125-1 | PGN-plus-P 125-2 | PGN-plus-P 125-1-AS | PGN-plus-P 125-2-AS | PGN-plus-P 125-1-IS | PGN-plus-P 125-2-IS |
|------------------------------------|-------|---------------------|---------------------|------------------------|------------------------|------------------------|------------------------|
| ID | | 0318568 | 0318569 | 0318570 | 0318571 | 0318572 | 0318573 |
| Stroke per jaw | [mm] | 13 | 6 | 13 | 6 | 13 | 6 |
| Closing/opening force | [N] | 1400/1520 | 3000/3250 | 2000/- | 4200/- | -/2120 | -/4450 |
| Min. spring force | [N] | | | 600 | 1200 | 600 | 1200 |
| Weight | [kg] | 1.4 | 1.4 | 1.9 | 1.9 | 1.9 | 1.9 |
| Recommended workpiece weight | [kg] | 7 | 15 | 7 | 15 | 7 | 15 |
| Cylinder volume per double stroke | [cm³] | 110 | 110 | 160 | 160 | 185 | 185 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.09/0.09 | 0.09/0.09 | 0.08/0.12 | 0.08/0.12 | 0.12/0.08 | 0.12/0.08 |
| Closing/opening time with spring | [s] | | | 0.15 | 0.15 | 0.15 | 0.15 |
| Max. permissible finger length | [mm] | 200 | 185 | 185 | 170 | 185 | 170 |
| Max. permissible weight per finger | [kg] | 2.4 | 2.4 | 2.4 | 2.4 | 2.4 | 2.4 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 |
| Dimensions X x Y x Z | [mm] | 151 x 60 x 63 | 151 x 60 x 63 | 151 x 60 x 93 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1317584 | 1317585 | 1317590 | 1317591 | 1317592 | 1317593 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 1.6 | 1.6 | 2.1 | 2.1 | 2.1 | 2.1 |
| Corrosion-protected version | | 38318568 | 38318569 | 38318570 | 38318571 | 38318572 | 38318573 |
| High-temperature version | | 39318568 | 39318569 | 39318570 | 39318571 | 39318572 | 39318573 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 0318574 | 0318575 | 0318576 | 0318577 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- (2) Finger connection
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22..
- (91) Sensor IN ...
- 92 Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection





 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M5




3 Adapter

(4) Grippers

The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.


Gripping force maintenance version AS/IS



10 Projection applies only for AS version

The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- 9 For mounting screw connection diagram, see basic version
- 15) Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|--------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 125 | 1347572 |

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.


Precision version



- 20 For version AS/IS
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

SDV-P pressure maintenance valve



4 Grippers


90 SDV-P pressure maintenance

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter |
|---------------------|----------------|---------------------------|
| | | [mm] |
| Pressure maintenanc | e valve | |
| SDV-P 04 | 0403130 | 6 |
| SDV-P 07 | 0403131 | 8 |
| Pressure maintenanc | e valve with a | ir bleed screw |
| SDV-P 04-E | 0300120 | 6 |
| SDV-P 07-E | 0300121 | 8 |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

SDV-P E-P pressure maintenance valve




- (3) Adapter
- 90 SDV-P E-P pressure maintenance valve
- 91) 2-finger parallel gripper PGN-plus/PGN-plus-P
- 92 2-finger parallel gripper JGP-P
- 93 2-finger angular gripper PWG-plus
- (94) 2-finger parallel gripper PGB
- 95) Sealed DPG-plus gripper

The SDV-P E-P pressure maintenance valves ensure that the pressure in the piston chamber is maintained temporarily during an emergency stop. SDV-P E-P can be directly connected to the listed grippers without the need for additional pneumatic hoses.

| Description | ID |
|-------------------|------------|
| Pressure maintena | ance valve |
| SDV-P 125-F-P | 0300127 |

Pneumatic positioning device PPD




The PPD allows flexibility in all applications with pneumatic grippers through free positioning, gripping force and speed adjustment.

| Description | ID |
|---------------------------------------|----------------|
| Pneumatic positioning device | |
| PPD 20-IOL | 1540700 |
| Adapter | |
| A GGN0804-1204-A | 1540691 |
| 10-Link connection cable | |
| KA GGN1205-1212-IOL-00100-A | 1540697 |
| Voltage supply connection cable - cab | le track compa |
| KA GLN12B05-LK-01000-A | 1540660 |
| Cable extension | |
| KV GGN0804-I0-00150-A | 1540662 |
| KV GGN0804-10-00300-A | 1540663 |
| Assembly set | |
| Assembly set PPD | 1540705 |

① In addition to the PPD, a position sensor (SCHUNK IO-Link sensor or analog sensor (4...20 mA)) is required.

Protective cover HUE PGN-plus 125




9 For mounting screw connection diagram, see basic version

The HUE protective cover fully protects the gripper against external influences. The cover is suitable for applications of up to IP65 if an additional sealing of the cover bottom is provided. For detailed information, please see the HUE series. The connection diagram shifts by the height of the intermediate jaw.

| Description | ID | IP protection class |
|------------------|---------|---------------------|
| Protection cover | | |
| HUE PGN-plus 125 | 0371483 | 65 |

The HUE protective cover is not suitable for use on grippers with gripping force maintenance. An inductive monitoring of the gripper in connection with the HUE protective cover is not possible. SCHUNK recommends the use of magnetic sensors that are approved for the respective gripper variant.

BSWS jaw quick-change jaw systems



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | |
|---|---------|-------------------|--|--|
| Jaw quick-change system adapt | ter pin | | | |
| BSWS-A 125 | 0303028 | 2 | | |
| BSWS-AR 125 | 0300095 | 2 | | |
| Quick-change jaw system base | | | | |
| BSWS-B 125 | 0303029 | 1 | | |
| Jaw quick-change system finger blank | | | | |
| BSWS-ABR-PGZN-plus 125 | 0300075 | 1 | | |
| BSWS-SBR-PGZN-plus 125 | 0300085 | 1 | | |
| Jaw quick-change system locking mechanism | | | | |
| BSWS-UR 125 | 0302994 | 1 | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used. This accessory product can be used in combination with the gripper PGN-plus-P 125 only with stroke variant -1.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------|-------------|--|
| PGN-plus-P | 125 | -1 (6 bar) | | |
| PGN-plus-P | 125 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 125 | -2 (6 bar) | | |
| PGN-plus-P | 125 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-M



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.


| Description | ID | Scope of delivery | | | |
|---|-------------------------------------|-------------------|--|--|--|
| Jaw quick-change system adapt | Jaw quick-change system adapter pin | | | | |
| BSWS-A 125 | 0303028 | 2 | | | |
| BSWS-AR 125 | 0300095 | 2 | | | |
| Quick-change jaw system base | | | | | |
| BSWS-BM 125 | 1302006 | 1 | | | |
| Jaw quick-change system finger blank | | | | | |
| BSWS-ABRM-PGZN-plus 125 | 1420854 | 1 | | | |
| Jaw quick-change system locking mechanism | | | | | |
| BSWS-URM 125 | 1398404 | 1 | | | |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------------------------|-------------|--|
| PGN-plus-P | 125 | -1 (6 bar) | | |
| PGN-plus-P | 125 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 125 | -2 (6 bar) | | |
| PGN-plus-P | 125 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined w | Can be combined without restrictions | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

Jaw quick-change system BSWS-R



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| ID | Scope of delivery | | | | |
|---|--|--|--|--|--|
| Description ID Scope of delivery Jaw quick-change system adapter pin | | | | | |
| | 2 | | | | |
| 0300033 | - | | | | |
| 1555937 | 1 | | | | |
| 1333331 | - | | | | |
| 1555972 | 1 | | | | |
| BSWS-SR 125 1555972 1 Attachment kit for proximity switch | | | | | |
| 1561467 | 1 | | | | |
| | | | | | |
| 0301578 | | | | | |
| 0301478 | | | | | |
| 0301550 | | | | | |
| | 2r pin 0300095 1555937 1555972 ttch 1561467 0301578 0301478 | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------------------------|-------------|--|
| PGN-plus-P | 125 | -1 (6 bar) | | |
| PGN-plus-P | 125 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 125 | -2 (6 bar) | | |
| PGN-plus-P | 125 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined w | Can be combined without restrictions | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

ZBA-L-plus 125 intermediate jaws



- (2) Finger connection
- (56) Included in the scope of delivery
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- (81) Not included in the scope of delivery


The optional ZBA-L-plus intermediate jaws allow the screw connection diagram of the top jaws to be rotated by 90°. This makes it easier to design and produce top jaws (particularly for long versions) because no deep through-bores are required.

| Description | ID | Material | Finger interface | Scope of delivery |
|------------------|---------|----------|---------------------|-------------------|
| Intermediate jaw | | | | |
| ZBA-L-plus 125 | 0311752 | Aluminum | PGN-plus | 1 |

PGN-plus-P 125

Universal gripper

UZB 125 universal intermediate jaw



- 1 Gripper connection
- 2 Finger connection
- (54) Optional right or left connection
- (57) Locking
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The drawing shows the UZB universal intermediate jaw. The fully removable UZB-S slide (can also be ordered separately) allows for a quick jaw change.

| Description | ID | Grid dimension | |
|--------------------------------------|---------|----------------|--|
| | | [mm] | |
| Universal intermediate j | aw | | |
| UZB 125 | 0300045 | 3 | |
| Finger blank | | | |
| ABR-PGZN-plus 125 | 0300013 | | |
| SBR-PGZN-plus 125 | 0300023 | | |
| Slide for universal intermediate jaw | | | |
| UZB-S 125 | 5518273 | 3 | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked.

Fields of application

| Series | Size | Variant | Suitability |
|------------|--|--------------------|-------------|
| PGN-plus-P | 125 | -1 (6 bar) | |
| PGN-plus-P | 125 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 125 | -2 (6 bar) | |
| PGN-plus-P | 125 | -2-AS/2-IS (6 bar) | 0000 |
| Legend | | | |
| | Can be combined without restrictions | | |
| | Use with restrictions (see loading limits) | | |
| 0000 | cannot be combined | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Finger blanks ABR/SBR-PGZN-plus 125




- (2) Finger connection
- (72) Fit for centering sleeves

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|-------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 125 | 0300013 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 125 | 0300023 | Steel (1.7131) | 1 |

When finger blanks are used, the closing stroke of individual gripper series may be limited. Please check this in detail in advance using the CAD data and adjust the reworking of the fingers accordingly.

Tolerance compensation unit TCU




90 Monitoring of locking

Grippers can be directly mounted without an adapter plate. Tolerance compensation unit and gripper have an identical screw connection diagram. Therefore the tolerance compensation units can be assembled later. Please consider the additional assembly height of the tolerance compensation unit. For details please refer to our catalog robot accessories.

| Description | ID | Locking | Deflection | Often combined |
|-------------------|---------|---------|-----------------|----------------|
| Compensation unit | | | | |
| TCU-P-125-3-MV | 0324828 | yes | ±1°/±1,5°/±1,5° | • |
| TCU-P-125-3-0V | 0324829 | no | ±1°/±1,5°/±1,5° | |

Compact change system for grippers




- 4 Grippers
- (90) CWA compact change adapter
- (91) CWK compact change master
- 92) A-CWA adapter plate
- (93) CWA compact change adapter
- (94) CWK compact change master

Grippers can be directly mounted without an adapter plate. For details see our catalog Gripping or Robot Accessories.

| Description | ID |
|---------------------------|---------|
| CWA compact change | adapter |
| CWA-125-P | 0305826 |
| CWK compact change master | |
| CWK-125-P | 0305825 |

Compensation unit AGE-F




90 Monitoring

The unit has direct connection possibilities for different grippers of the PGN-plus, PGN-plus-P and PZN-plus series. For more detailed information, please refer to the main view.

| Description | ID | Compensation XY | Reset force | Often combined |
|-------------------|---------|--------------------|-------------|----------------|
| | | [mm] | [N] | |
| Compensation unit | | | | |
| AGE-F-XY-080-1 | 0324960 | ± 5 | 39 | |
| AGE-F-XY-080-2 | 0324961 | ± 5 | 85 | |
| AGE-F-XY-080-3 | 0324962 | ± 5 | 90 | • |

 $\ensuremath{\textcircled{\scriptsize 1}}$ Due to the interfering contour, monitoring of the gripper is not possible.


Modular Assembly Automation



- (4) Grippers
- (91) ASG adapter plate
- (90) Linear module CLM/KLM/LM/ELP/ ELM/ELS/HLM

Grippers and linear modules can be combined with standard adapter plates from the modular assembly system. For more information see our main catalog "Modular Assembly Automation".

Inductive proximity switches




- 17 Cable outlet
- 91) Sensor IN..-SA
- 90 Sensor IN ...

Directly mounted end position monitoring.

| Inductive proximity switch IN 80-S-M12 0301578 IN 80-S-M8 0301478 ● INK 80-S 0301550 Inductive proximity switch with lateral cable outlet IN 80-S-M12-SA 0301587 IN 80-S-M8-SA 0301483 ● INK 80-S-M8-SA 0301566 Connection cables KA BG08-L 3P-0300-PNP 0301622 ● KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 03016369 KA BW08-L 3P-0500-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW08-L 3P-0500-PNP 0301503 KA BW12-L 3P-0500-PNP 0301503 KA BW12-L 3P-0500-PNP 0301507 | |
|---|--|
| IN 80-S-M8 INK 80-S Inductive proximity switch with lateral cable outlet IN 80-S-M12-SA IN 80-S-M8-SA INK 80-S-M8-SA INK 80-S-SA Connection cables KA BG08-L 3P-0300-PNP KA BG08-L 3P-0500-PNP MA BG12-L 3P-0500-PNP MA BW08-L 3P-0300-PNP MA BW08-L 3P-0500-PNP MA BW08-L 3P-0300-PNP MA BW12-L 3P-0300-PNP | |
| INK 80-S Inductive proximity switch with lateral cable outlet IN 80-S-M12-SA IN 80-S-M8-SA INK 80-S-SA INK 80-S-S | |
| Inductive proximity switch with lateral cable outlet IN 80-S-M12-SA 0301587 IN 80-S-M8-SA 0301483 ● INK 80-S-SA 0301566 Connection cables KA BG08-L 3P-0300-PNP 0301622 ● KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 03016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW08-L 3P-0300-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| IN 80-S-M12-SA 0301587 IN 80-S-M8-SA 0301483 INK 80-S-SA 0301566 Connection cables KA BG08-L 3P-0300-PNP 0301622 KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 0301594 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| IN 80-S-M8-SA 0301483 | |
| INK 80-S-SA 0301566 Connection cables KA BG08-L 3P-0300-PNP 0301622 KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| Connection cables KA BG08-L 3P-0300-PNP 0301622 KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BG08-L 3P-0300-PNP 0301622 KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BG08-L 3P-0500-PNP 0301623 KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BG12-L 3P-0500-PNP 30016369 KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BW08-L 3P-0300-PNP 0301594 KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BW08-L 3P-0500-PNP 0301502 KA BW12-L 3P-0300-PNP 0301503 | |
| KA BW12-L 3P-0300-PNP 0301503 | |
| | |
| KA BW12-L 3P-0500-PNP 0301507 | |
| | |
| Clip for connector/socket | |
| CLI-M12 0301464 | |
| CLI-M8 0301463 | |
| Cable extension | |
| KV BG12-SG12 3P-0030-PNP 0301999 | |
| KV BG12-SG12 3P-0060-PNP 0301998 | |
| KV BW08-SG08 3P-0030-PNP 0301495 | |
| KV BW08-SG08 3P-0100-PNP 0301496 | |
| KV BW08-SG08 3P-0200-PNP 0301497 | |
| KV BW12-SG12 3P-0030-PNP 0301595 | |
| KV BW12-SG12 3P-0100-PNP 0301596 | |
| KV BW12-SG12 3P-0200-PNP 0301597 | |
| Sensor distributor | |
| V2-M12 0301776 • | |
| V2-M8 0301775 • | |
| V4-M8 0301746 | |
| V8-M8 0301751 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Flexible position sensor




- 90 FPS-S sensor
- 92 Cable extension
- 91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID |
|-------------------------|---------|
| Attachment kit for FPS | |
| AS-FPS-PGN-plus-P 125-1 | 1363894 |
| AS-FPS-PGN-plus-P 125-2 | 1366173 |
| Sensor | |
| FPS-S M8 | 0301704 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Cable extension | |
| KV BG08-SG08 3P-0050 | 0301598 |
| KV BG08-SG08 3P-0100 | 0301599 |
| | |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS




- (17) Cable outlet
- 91) Sensor MMS 22...-SA
- 90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|-----------------------------------|-----------------|----------------|
| Electronic magnetic switch | | |
| MMS 22-S-M8-PNP | 0301032 | • |
| MMSK 22-S-PNP | 0301034 | |
| Electronic magnetic switches with | lateral cable o | outlet |
| MMS 22-S-M8-PNP-SA | 0301042 | • |
| MMSK 22-S-PNP-SA | 0301044 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| Sensor distributor | | |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |
| | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1




- (17) Cable outlet
- 91) Sensor MMS 22 ..-PI1-...-SA
- 90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined |
|------------------------------|----------------|-----------------|
| Programmable magnetic switch | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • |
| MMSK 22-PI1-S-PNP | 0301162 | |
| Programmable magnetic switch | with lateral c | able outlet |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • |
| MMSK 22-PI1-S-PNP-SA | 0301168 | |
| Programmable magnetic switch | with stainles | s steel housing |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • |
| MMSK 22-PI1-S-PNP-HD | 0301112 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI2



(17) Cable outlet


90 MMS 22...-PI2-... sensor

Position monitoring with two programmable positions per sensor and electronics integrated in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| ID | Often combined |
|----------------|---|
| | |
| 0301180 | • |
| 0301182 | |
| with lateral c | able outlet |
| 0301186 | • |
| 0301188 | |
| with stainless | s steel housing |
| 0301130 | • |
| 0301132 | |
| | 0301180 0301182 with lateral c 0301186 0301188 with stainles: 0301130 |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

MMS-P programmable magnetic switch




(74) Limit stop for sensor

Position monitoring with two programmable positions per sensor. End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|------------------------------|---------|----------------|
| Programmable magnetic switch | h | |
| MMSK-P 22-S-PNP | 0301371 | |
| MMS-P 22-S-M8-PNP | 0301370 | • |
| Connection cables | | |
| KA GLN0804-LK-00500-A | 0307767 | • |
| KA GLN0804-LK-01000-A | 0307768 | |
| KA WLN0804-LK-00500-A | 0307765 | |
| KA WLN0804-LK-01000-A | 0307766 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Sensor distributor | | |
| V2-M8-4P-2XM8-3P | 0301380 | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

Analog position sensor MMS-A




(74) Limit stop for sensor

Non-contact measuring, analog multi-position monitoring for any number of positions, easy to assemble in the C-slot. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the chart provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-10V-M08 | 0315825 |
| MMS 22-A-10V-M12 | 0315828 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

Flexible position sensor with MMS-A




- 74 Limit stop for sensor
- (91) FPS-F5 evaluation electronic
- 90 MMS 22-A-... sensor
- (92) Connection cables

Flexible position monitoring of up to five positions. Sensor can be taught using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-05V-M08 | 0315805 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Sensor Teaching Tool | |
| MT-MMS 22-PI | 0301030 |
| Connection cables | |
| KA BG16-L 12P-1000 | 0301801 |

When using an FPS system, one MMS 22-A-05V and one evaluation electronics (FPS-F5) are required per each gripper, as well as an attachment kit (AS), if listed. On option, cable extensions (KV) are available - see catalog chapter "Accessories."

Programmable magnetic switch MMS-I0-Link




(74) Limit stop for sensor

Sensor for multi-position monitoring through detection of the complete gripper stroke. The sensor is mounted directly in the C-slot of the gripper. The sensor is programmed for the gripper via the IO-Link interface, Magnet teaching tool MT (included in scope of delivery; ID 0301030) or the ST plug teaching tool (not included in scope of delivery; ID 0301026). An IO-Link master is required for operation.

| Description | ID |
|------------------|--------------|
| Programmable mag | netic switch |
| MMS 22-I0L-M08 | 0315830 |
| MMS 22-I0L-M12 | 0315835 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

APS-Z80 analog position sensor



Non-contact measuring, analog multi-position monitoring for any number of positions.


| Description | ID | Often combined |
|-----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 125-1 | 1366226 | |
| AS-APS-Z80-PGN-plus-P 125-2 | 1366228 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |

When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.


Universal gripper




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 160-1 | PGN-plus-P 160-2 | PGN-plus-P 160-1-AS | PGN-plus-P 160-2-AS | PGN-plus-P 160-1-IS | PGN-plus-P 160-2-IS |
|------------------------------------|-------|---------------------|---------------------|------------------------|------------------------|------------------------|------------------------|
| ID | | 0318592 | 0318593 | 0318594 | 0318595 | 0318596 | 0318597 |
| Stroke per jaw | [mm] | 16 | 8 | 16 | 8 | 16 | 8 |
| Closing/opening force | [N] | 2500/2800 | 4900/5500 | 3300/- | 6300/- | -/3600 | -/6900 |
| Min. spring force | [N] | | | 800 | 1400 | 800 | 1400 |
| Weight | [kg] | 2.8 | 2.9 | 3.6 | 3.7 | 3.5 | 3.7 |
| Recommended workpiece weight | [kg] | 12.5 | 24.5 | 12.5 | 24.5 | 12.5 | 24.5 |
| Cylinder volume per double stroke | [cm³] | 200 | 200 | 355 | 355 | 380 | 380 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.1/0.1 | 0.1/0.1 | 0.1/0.2 | 0.1/0.2 | 0.2/0.1 | 0.2/0.1 |
| Closing/opening time with spring | [s] | | | 0.20 | 0.20 | 0.20 | 0.20 |
| Max. permissible finger length | [mm] | 245 | 225 | 225 | 215 | 225 | 215 |
| Max. permissible weight per finger | [kg] | 3.8 | 3.8 | 3.8 | 3.8 | 3.8 | 3.8 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 | 0.01 |
| Dimensions X x Y x Z | [mm] | 192 x 72 x 77 | 192 x 72 x 77 | 192 x 72 x 117 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1317645 | 1317647 | 1317649 | 1317652 | 1317653 | 1317654 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 3.2 | 3.2 | 4 | 4 | 4 | 4 |
| Corrosion-protected version | | 1317631 | 1317632 | 1317638 | 1317639 | 1317641 | 1317644 |
| High-temperature version | | 1317594 | 1317596 | 1317599 | 1317600 | 1317625 | 1317629 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 1317656 | 1317659 | 1317658 | 1317660 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- 2 Finger connection
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22..
- (91) Sensor IN ...
- (92) Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection





 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.


Hose-free direct connection M5



3 Adapter 4 Grippers


The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.

Gripping force maintenance version AS/IS



The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- 9 For mounting screw connection diagram, see basic version
- 15) Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|--------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 160 | 1347575 |

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.


Precision version



- 20 For version AS/IS
- 72 Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

SDV-P pressure maintenance valve



4 Grippers


90 SDV-P pressure maintenance

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter | | |
|---|---------|---------------------------|--|--|
| | | [mm] | | |
| Pressure maintenance | e valve | | | |
| SDV-P 07 | 0403131 | 8 | | |
| Pressure maintenance valve with air bleed screw | | | | |
| SDV-P 07-E | 0300121 | 8 | | |
| SDV-P 10-E | 0300109 | 10 | | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

Pneumatic positioning device PPD




The PPD allows flexibility in all applications with pneumatic grippers through free positioning, gripping force and speed adjustment.

| Description | ID |
|--|---------------|
| Pneumatic positioning device | |
| PPD 20-IOL | 1540700 |
| Adapter | |
| A GGN0804-1204-A | 1540691 |
| 10-Link connection cable | |
| KA GGN1205-1212-IOL-00100-A | 1540697 |
| Voltage supply connection cable - cabl | e track compa |
| KA GLN12B05-LK-01000-A | 1540660 |
| Cable extension | |
| KV GGN0804-I0-00150-A | 1540662 |
| KV GGN0804-10-00300-A | 1540663 |
| Assembly set | |
| Assembly set PPD | 1540705 |

① In addition to the PPD, a position sensor (SCHUNK IO-Link sensor or analog sensor (4...20 mA)) is required.

Protective cover HUE PGN-plus 160




(9) For mounting screw connection diagram, see basic version

The HUE protective cover fully protects the gripper against external influences. The cover is suitable for applications of up to IP65 if an additional sealing of the cover bottom is provided. For detailed information, please see the HUE series. The connection diagram shifts by the height of the intermediate jaw.

| Description | ID | IP protection class |
|------------------|---------|---------------------|
| Protection cover | | |
| HUE PGN-plus 160 | 0371484 | 65 |

The HUE protective cover is not suitable for use on grippers with gripping force maintenance. An inductive monitoring of the gripper in connection with the HUE protective cover is not possible. SCHUNK recommends the use of magnetic sensors that are approved for the respective gripper variant.

BSWS jaw quick-change jaw systems



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.


| Description | ID | Scope of delivery | | | | |
|---|-------------------------------------|-------------------|--|--|--|--|
| Jaw quick-change system adapt | Jaw quick-change system adapter pin | | | | | |
| BSWS-A 160 | 0303030 | 2 | | | | |
| BSWS-AR 160 | 0300096 | 2 | | | | |
| Quick-change jaw system base | | | | | | |
| BSWS-B 160 | 0303031 | 1 | | | | |
| Jaw quick-change system finger blank | | | | | | |
| BSWS-ABR-PGZN-plus 160 | 0300076 | 1 | | | | |
| BSWS-SBR-PGZN-plus 160 | 0300086 | 1 | | | | |
| Jaw quick-change system locking mechanism | | | | | | |
| BSWS-UR 160 | 0302995 | 1 | | | | |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | | |
|------------|-------------|--|----------------|--|--|
| PGN-plus-P | 160 | -1 (6 bar) | | | |
| PGN-plus-P | 160 | -1-AS/1-IS (6 bar | | | |
| PGN-plus-P | 160 | -2 (6 bar) | | | |
| PGN-plus-P | 160 | -2-AS/2-IS (6 bar |) == □□ | | |
| Legend | | | | | |
| | Can be com | Can be combined without restrictions | | | |
| | Use with re | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be | cannot be combined | | | |

Jaw quick-change system BSWS-M



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | | |
|---|---------|-------------------|--|--|--|
| Jaw quick-change system adapter pin | | | | | |
| BSWS-A 160 | 0303030 | 2 | | | |
| BSWS-AR 160 | 0300096 | 2 | | | |
| Quick-change jaw system base | | | | | |
| BSWS-BM 160 | 1418962 | 1 | | | |
| Jaw quick-change system finger blank | | | | | |
| BSWS-ABRM-PGZN-plus 160 | 1420855 | 1 | | | |
| Jaw quick-change system locking mechanism | | | | | |
| BSWS-URM 160 | 1420541 | 1 | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | | |
|------------|--|--------------------|-------------|--|--|
| PGN-plus-P | 160 | -1 (6 bar) | | | |
| PGN-plus-P | 160 | -1-AS/1-IS (6 bar) | | | |
| PGN-plus-P | 160 | -2 (6 bar) | | | |
| PGN-plus-P | 160 | -2-AS/2-IS (6 bar) | | | |
| Legend | | | | | |
| | Can be combined without restrictions | | | | |
| | Use with restrictions (see loading limits) | | | | |
| | cannot be combined | | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-R



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.


| Description | ID | Scope of delivery | | | | |
|-------------------------------------|-------------------------------------|-------------------|--|--|--|--|
| Jaw quick-change system adapt | law quick-change system adapter pin | | | | | |
| BSWS-AR 160 | 0300096 | 2 | | | | |
| Quick-change jaw system base | | | | | | |
| BSWS-BR 160 | 1555940 | 1 | | | | |
| Storage system | | | | | | |
| BSWS-SR 160 | 1555974 | 1 | | | | |
| Attachment kit for proximity switch | | | | | | |
| AS-IN80-BSWS-SR 125/160 | 1561467 | 1 | | | | |
| Inductive proximity switch | | | | | | |
| IN 80-S-M12 | 0301578 | | | | | |
| IN 80-S-M8 | 0301478 | | | | | |
| INK 80-S | 0301550 | | | | | |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | | |
|------------|-------------|--|-----------------|--|--|
| PGN-plus-P | 160 | -1 (6 bar) | | | |
| PGN-plus-P | 160 | -1-AS/1-IS (6 bar | ·) | | |
| PGN-plus-P | 160 | -2 (6 bar) | | | |
| PGN-plus-P | 160 | -2-AS/2-IS (6 bai | r) ■ ■□□ | | |
| Legend | | | | | |
| | Can be com | Can be combined without restrictions | | | |
| | Use with re | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be c | cannot be combined | | | |

ZBA-L-plus 160 intermediate jaws




- 2 Finger connection
- (56) Included in the scope of delivery
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 81) Not included in the scope of delivery

The optional ZBA-L-plus intermediate jaws allow the screw connection diagram of the top jaws to be rotated by 90°. This makes it easier to design and produce top jaws (particularly for long versions) because no deep through-bores are required.

| Description | ID | Material | Finger interface | Scope of delivery | |
|------------------|---------|----------|---------------------|-------------------|--|
| Intermediate jaw | | | | | |
| ZBA-L-plus 160 | 0311762 | Aluminum | PGN-plus 160 | 1 | |

UZB 160 universal intermediate jaw



- 1 Gripper connection
- 2 Finger connection
- (54) Optional right or left connection
- 57 Locking
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The drawing shows the UZB universal intermediate jaw. The fully removable UZB-S slide (can also be ordered separately) allows for a quick jaw change.

| Description | ID | Grid dimension | | |
|--------------------------------------|---------|----------------|--|--|
| | | [mm] | | |
| Universal intermediate jaw | | | | |
| UZB 160 | 0300046 | 4 | | |
| Finger blank | | | | |
| ABR-PGZN-plus 160 | 0300014 | | | |
| SBR-PGZN-plus 160 | 0300024 | | | |
| Slide for universal intermediate jaw | | | | |
| UZB-S 160 | 5518274 | 4 | | |

① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked.


Fields of application

| Series | Size | Variant | Suitability | | |
|------------|--|--------------------|-------------|--|--|
| PGN-plus-P | 160 | -1 (6 bar) | | | |
| PGN-plus-P | 160 | -1-AS/1-IS (6 bar) | | | |
| PGN-plus-P | 160 | -2 (6 bar) | | | |
| PGN-plus-P | 160 | -2-AS/2-IS (6 bar) | 0000 | | |
| Legend | | | | | |
| | Can be combined without restrictions | | | | |
| | Use with restrictions (see loading limits) | | | | |
| 0000 | cannot be combined | | | | |

PGN-plus-P 160

Universal gripper

Finger blanks ABR/SBR-PGZN-plus 160



(2) Finger connection


72) Fit for centering sleeves

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|-------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 160 | 0300014 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 160 | 0300024 | Steel (1.7131) | 1 |

When finger blanks are used, the closing stroke of individual gripper series may be limited. Please check this in detail in advance using the CAD data and adjust the reworking of the fingers accordingly.

Tolerance compensation unit TCU




90 Monitoring of locking

Grippers can be directly mounted without an adapter plate. Tolerance compensation unit and gripper have an identical screw connection diagram. Therefore the tolerance compensation units can be assembled later. Please consider the additional assembly height of the tolerance compensation unit. For details please refer to our catalog robot accessories.

| Description | ID | Locking | Deflection | Often combined |
|-------------------|---------|---------|---------------|----------------|
| Compensation unit | | | | |
| TCU-P-160-3-MV | 0324846 | yes | ±1°/±2°/±1,5° | • |
| TCU-P-160-3-0V | 0324847 | no | ±1°/±2°/±1.5° | |

Modular Assembly Automation




(4) Grippers

(91) ASG adapter plate

90 Linear module CLM/KLM/LM/ELP/ ELM/ELS/HLM

Grippers and linear modules can be combined with standard adapter plates from the modular assembly system. For more information see our main catalog "Modular Assembly Automation".

Inductive proximity switches



- $\widehat{17}$ Cable outlet
- 91) Sensor IN..-SA
- 90 Sensor IN ...

Directly mounted end position monitoring.


| Description | ID | Often combined | | | |
|------------------------------------|----------------|----------------|--|--|--|
| Inductive proximity switch | | | | | |
| IN 80-S-M12 | 0301578 | | | | |
| IN 80-S-M8 | 0301478 | • | | | |
| INK 80-S | 0301550 | | | | |
| Inductive proximity switch with la | teral cable ou | tlet | | | |
| IN 80-S-M12-SA | 0301587 | | | | |
| IN 80-S-M8-SA | 0301483 | • | | | |
| INK 80-S-SA | 0301566 | | | | |
| Connection cables | | | | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • | | | |
| KA BG08-L 3P-0500-PNP | 0301623 | | | | |
| KA BG12-L 3P-0500-PNP | 30016369 | | | | |
| KA BW08-L 3P-0300-PNP | 0301594 | | | | |
| KA BW08-L 3P-0500-PNP | 0301502 | | | | |
| KA BW12-L 3P-0300-PNP | 0301503 | | | | |
| KA BW12-L 3P-0500-PNP | 0301507 | | | | |
| Clip for connector/socket | | | | | |
| CLI-M12 | 0301464 | | | | |
| CLI-M8 | 0301463 | | | | |
| Cable extension | | | | | |
| KV BG12-SG12 3P-0030-PNP | 0301999 | | | | |
| KV BG12-SG12 3P-0060-PNP | 0301998 | | | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | | | | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | | | | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • | | | |
| KV BW12-SG12 3P-0030-PNP | 0301595 | | | | |
| KV BW12-SG12 3P-0100-PNP | 0301596 | | | | |
| KV BW12-SG12 3P-0200-PNP | 0301597 | | | | |
| Sensor distributor | | | | | |
| V2-M12 | 0301776 | • | | | |
| V2-M8 | 0301775 | • | | | |
| V4-M8 | 0301746 | | | | |
| V8-M8 | 0301751 | | | | |
| | | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

PGN-plus-P 160

Universal gripper

Flexible position sensor




- 90 FPS-S sensor
- 92 Cable extension
- (91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID |
|-------------------------|---------|
| Attachment kit for FPS | |
| AS-FPS-PGN-plus-P 160-1 | 1388823 |
| AS-FPS-PGN-plus-P 160-2 | 1388826 |
| Sensor | |
| FPS-S M8 | 0301704 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Cable extension | |
| KV BG08-SG08 3P-0050 | 0301598 |
| KV BG08-SG08 3P-0100 | 0301599 |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS




- 17) Cable outlet
- 91) Sensor MMS 22...-SA
- 90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| . 1 | | | | |
|-----------------------------------|-----------------|----------------|--|--|
| Description | ID | Often combined | | |
| Electronic magnetic switch | | | | |
| MMS 22-S-M8-PNP | 0301032 | • | | |
| MMSK 22-S-PNP | 0301034 | | | |
| Electronic magnetic switches with | lateral cable o | outlet | | |
| MMS 22-S-M8-PNP-SA | 0301042 | • | | |
| MMSK 22-S-PNP-SA | 0301044 | | | |
| Connection cables | | | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • | | |
| KA BG08-L 3P-0500-PNP | 0301623 | | | |
| KA BW08-L 3P-0300-PNP | 0301594 | | | |
| KA BW08-L 3P-0500-PNP | 0301502 | | | |
| Clip for connector/socket | | | | |
| CLI-M8 | 0301463 | | | |
| Cable extension | | | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | | | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | | | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • | | |
| Sensor distributor | | | | |
| V2-M8 | 0301775 | • | | |
| V4-M8 | 0301746 | | | |
| V8-M8 | 0301751 | | | |
| | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1



(17) Cable outlet

(91) Sensor MMS 22 ..-PI1-...-SA


90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | |
|---|---------|----------------|--|--|--|
| Programmable magnetic switch | | | | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • | | | |
| MMSK 22-PI1-S-PNP | 0301162 | | | | |
| Programmable magnetic switch with lateral cable outlet | | | | | |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • | | | |
| MMSK 22-PI1-S-PNP-SA | 0301168 | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • | | | |
| MMSK 22-PI1-S-PNP-HD | 0301112 | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI2



(17) Cable outlet


90 MMS 22...-PI2-... sensor

Position monitoring with two programmable positions per sensor and electronics integrated in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | | |
|---|------------------------------|----------------|--|--|--|--|
| Programmable magnetic switch | Programmable magnetic switch | | | | | |
| MMS 22-PI2-S-M8-PNP | 0301180 | • | | | | |
| MMSK 22-PI2-S-PNP | 0301182 | | | | | |
| Programmable magnetic switch with lateral cable outlet | | | | | | |
| MMS 22-PI2-S-M8-PNP-SA | 0301186 | • | | | | |
| MMSK 22-PI2-S-PNP-SA | 0301188 | | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | | |
| MMS 22-PI2-S-M8-PNP-HD | 0301130 | • | | | | |
| MMSK 22-PI2-S-PNP-HD | 0301132 | | | | | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

MMS-P programmable magnetic switch




(74) Limit stop for sensor

Position monitoring with two programmable positions per sensor. End position monitoring for mounting in the C-slot.

| Description | ID | Often combined | | | |
|------------------------------|---------|----------------|--|--|--|
| Programmable magnetic switch | :h | | | | |
| MMSK-P 22-S-PNP | 0301371 | | | | |
| MMS-P 22-S-M8-PNP | 0301370 | • | | | |
| Connection cables | | | | | |
| KA GLN0804-LK-00500-A | 0307767 | • | | | |
| KA GLN0804-LK-01000-A | 0307768 | | | | |
| KA WLN0804-LK-00500-A | 0307765 | | | | |
| KA WLN0804-LK-01000-A | 0307766 | | | | |
| Clip for connector/socket | | | | | |
| CLI-M8 | 0301463 | | | | |
| Sensor distributor | | | | | |
| V2-M8-4P-2XM8-3P | 0301380 | | | | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

Analog position sensor MMS-A




74) Limit stop for sensor

Non-contact measuring, analog multi-position monitoring for any number of positions, easy to assemble in the C-slot. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the chart provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-10V-M08 | 0315825 |
| MMS 22-A-10V-M12 | 0315828 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

Flexible position sensor with MMS-A




- (74) Limit stop for sensor
- 90 MMS 22-A-... sensor
- 91 FPS-F5 evaluation electronic
- 92 Connection cables

Flexible position monitoring of up to five positions. Sensor can be taught using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-05V-M08 | 0315805 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Sensor Teaching Tool | |
| MT-MMS 22-PI | 0301030 |
| Connection cables | |
| KA BG16-L 12P-1000 | 0301801 |

When using an FPS system, one MMS 22-A-05V and one evaluation electronics (FPS-F5) are required per each gripper, as well as an attachment kit (AS), if listed. On option, cable extensions (KV) are available - see catalog chapter "Accessories."

Programmable magnetic switch MMS-I0-Link



74) Limit stop for sensor

Sensor for multi-position monitoring through detection of the complete gripper stroke. The sensor is mounted directly in the C-slot of the gripper. The sensor is programmed for the gripper via the IO-Link interface, Magnet teaching tool MT (included in scope of delivery; ID 0301030) or the ST plug teaching tool (not included in scope of delivery; ID 0301026). An IO-Link master is required for operation.


| Description | ID |
|------------------|--------------|
| Programmable mag | netic switch |
| MMS 22-I0L-M08 | 0315830 |
| MMS 22-I0L-M12 | 0315835 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

PGN-plus-P 160

Universal gripper

APS-Z80 analog position sensor



Non-contact measuring, analog multi-position monitoring for any number of positions.


| Description | ID | Often combined |
|-----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 160-1 | 1374181 | |
| AS-APS-Z80-PGN-plus-P 160-2 | 1374182 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |

When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.


Universal gripper




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 200-1 | PGN-plus-P 200-2 | PGN-plus-P 200-1-AS | PGN-plus-P 200-2-AS | PGN-plus-P 200-1-IS | PGN-plus-P 200-2-IS |
|------------------------------------|-------|---------------------|---------------------|------------------------|------------------------|------------------------|------------------------|
| ID | | 0318616 | 0318617 | 0318618 | 0318619 | 0318620 | 0318621 |
| Stroke per jaw | [mm] | 25 | 14 | 25 | 14 | 25 | 14 |
| Closing/opening force | [N] | 3800/4050 | 6500/6900 | 5050/- | 8750/- | -/5500 | -/9350 |
| Min. spring force | [N] | | | 1250 | 2250 | 1450 | 2450 |
| Weight | [kg] | 5.2 | 5.4 | 6.8 | 7 | 6.6 | 6.8 |
| Recommended workpiece weight | [kg] | 19 | 32.5 | 19 | 32.5 | 19 | 32.5 |
| Cylinder volume per double stroke | [cm³] | 510 | 510 | 810 | 810 | 890 | 890 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.28/0.28 | 0.28/0.28 | 0.24/0.55 | 0.24/0.55 | 0.55/0.24 | 0.55/0.24 |
| Closing/opening time with spring | [s] | | | 0.40 | 0.40 | 0.40 | 0.40 |
| Max. permissible finger length | [mm] | 310 | 265 | 265 | 220 | 265 | 220 |
| Max. permissible weight per finger | [kg] | 6.5 | 6.5 | 6.5 | 6.5 | 6.5 | 6.5 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.02 | 0.02 | 0.02 | 0.02 | 0.02 | 0.02 |
| Dimensions X x Y x Z | [mm] | 234 x 100 x 91 | 234 x 100 x 91 | 234 x 100 x 141 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1317683 | 1317691 | 1317695 | 1317696 | 1317701 | 1317703 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 6 | 6 | 7.6 | 7.6 | 7.4 | 7.4 |
| Corrosion-protected version | | 1317675 | 1317676 | 1317678 | 1317679 | 1317680 | 1317681 |
| High-temperature version | | 1317663 | 1317665 | 1317666 | 1317667 | 1317670 | 1317674 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 1317705 | 1317706 | 1317708 | 1317710 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- (2) Finger connection
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22..
- (91) Sensor IN ...
- 92 Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection






 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M5




The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.

Gripping force maintenance version AS/IS



The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- 9 For mounting screw connection diagram, see basic version
- 15) Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|--------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 200 | 1347583 |

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.


Precision version



- 20 For version AS/IS
- 72 Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

SDV-P pressure maintenance valve



4 Grippers


90 SDV-P pressure maintenance

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter | | |
|---|---------|---------------------------|--|--|
| | | [mm] | | |
| Pressure maintenance | e valve | | | |
| SDV-P 07 | 0403131 | 8 | | |
| Pressure maintenance valve with air bleed screw | | | | |
| SDV-P 07-E | 0300121 | 8 | | |
| SDV-P 10-E | 0300109 | 10 | | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

Pneumatic positioning device PPD




The PPD allows flexibility in all applications with pneumatic grippers through free positioning, gripping force and speed adjustment.

| Description | ID |
|--|---------------|
| Pneumatic positioning device | |
| PPD 40-IOL | 1540701 |
| Adapter | |
| A GGN0804-1204-A | 1540691 |
| 10-Link connection cable | |
| KA GGN1205-1212-IOL-00100-A | 1540697 |
| Voltage supply connection cable - cabl | e track compa |
| KA GLN12B05-LK-01000-A | 1540660 |
| Cable extension | |
| KV GGN0804-I0-00150-A | 1540662 |
| KV GGN0804-10-00300-A | 1540663 |
| Assembly set | |
| Assembly set PPD | 1540705 |

① In addition to the PPD, a position sensor (SCHUNK IO-Link sensor or analog sensor (4...20 mA)) is required.

BSWS jaw quick-change jaw systems



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | | | |
|-------------------------------|-------------------------------------|-------------------|--|--|--|--|
| Jaw quick-change system adapt | Jaw quick-change system adapter pin | | | | | |
| BSWS-A 200 | 0303032 | 2 | | | | |
| BSWS-AR 200 | 1453341 | 2 | | | | |
| Quick-change jaw system base | | | | | | |
| BSWS-B 200 | 0303033 | 1 | | | | |
| Jaw quick-change system | | | | | | |
| BSWS-ABR-PGZN-plus 200 | 1453347 | 1 | | | | |
| BSWS-UR 200 | 1451606 | 1 | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|-----------------------|-------------|
| PGN-plus-P | 200 | -1 (6 bar) | |
| PGN-plus-P | 200 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 200 | -2 (6 bar) | |
| PGN-plus-P | 200 | -2-AS/2-IS (6 bar) | |
| Legend | | | |
| | Can be combined w | ithout restrictions | |
| | Use with restriction | ns (see loading limit | s) |
| 0000 | cannot be combine | d | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-M



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery |
|-----------------|---------------|-------------------|
| Quick-change ja | aw system bas | se . |
| BSWS-BM 200 | 1419306 | 1 |
| Jaw quick-chan | ge system ada | apter pin |
| BSWS-A 200 | 0303032 | 2 |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|------------------------|-------------|
| PGN-plus-P | 200 | -1 (6 bar) | |
| PGN-plus-P | 200 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 200 | -2 (6 bar) | |
| PGN-plus-P | 200 | -2-AS/2-IS (6 bar) | |
| Legend | | | |
| | Can be combined w | ithout restrictions | |
| | Use with restriction | ns (see loading limits | 5) |
| | cannot be combine | d | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-R



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| accanca inistination, pr | case . erer to | the corresponding product. |
|----------------------------|----------------|----------------------------|
| Description | ID | Scope of delivery |
| Jaw quick-change system | adapter pin | |
| BSWS-AR 200 | 1453341 | 2 |
| Quick-change jaw system l | oase | |
| BSWS-BR 200 | 1555942 | 1 |
| Storage system | | |
| BSWS-SR 200 | 1555976 | 1 |
| Attachment kit for proximi | ty switch | |
| AS-IN80-BSWS-SR 200 | 1561469 | 1 |
| Inductive proximity switch | | |
| IN 80-S-M12 | 0301578 | |
| IN 80-S-M8 | 0301478 | |
| INK 80-S | 0301550 | |
| | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|-----------------------|-------------|
| PGN-plus-P | 200 | -1 (6 bar) | |
| PGN-plus-P | 200 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 200 | -2 (6 bar) | |
| PGN-plus-P | 200 | -2-AS/2-IS (6 bar) | |
| Legend | | | |
| | Can be combined w | ithout restrictions | |
| | Use with restriction | ns (see loading limit | s) |
| 0000 | cannot be combine | d | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

ZBA-L-plus 200 intermediate jaws




- (2) Finger connection
- (56) Included in the scope of delivery
- **72**) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 81) Not included in the scope of delivery

Optionally intermediate jaws can be used, enabling direct connection and alignment of top jaws and various standard accessories in Z-direction.

| Description | ID | Material | Finger interface | Scope of delivery |
|------------------|---------|----------|---------------------|-------------------|
| Intermediate jaw | | | | |
| ZBA-L-plus 200 | 0311772 | Aluminum | PGN-plus | 1 |

UZB 200 universal intermediate jaw



- 1 Gripper connection
- 2 Finger connection
- (54) Optional right or left connection
- 57 Locking
- 72 Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The drawing shows the UZB universal intermediate jaw. The fully removable UZB-S slide (can also be ordered separately) allows for a quick jaw change.

| Description | ID | Grid dimension |
|----------------------------|-------------|----------------|
| | | [mm] |
| Universal intermediate j | aw | |
| UZB 200 | 0300047 | 7 |
| Finger blank | | |
| ABR-PGZN-plus 200 | 0300015 | |
| SBR-PGZN-plus 200 | 0300025 | |
| Slide for universal intern | nediate jaw | |
| UZB-S 200 | 5518275 | 7 |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked.

Fields of application

| Series | Size | Variant | Suitability |
|------------|----------------------|-----------------------|-------------|
| PGN-plus-P | 200 | -1 (6 bar) | |
| PGN-plus-P | 200 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 200 | -2 (6 bar) | |
| PGN-plus-P | 200 | -2-AS/2-IS (6 bar) | 0000 |
| Legend | | | |
| | Can be combined w | rithout restrictions | |
| | Use with restriction | ns (see loading limit | s) |
| 0000 | cannot be combine | d | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Finger blanks ABR/SBR-PGZN-plus 200




- 2 Finger connection
- 90 ABR-PGZN-plus
- 72) Fit for centering sleeves
- 91) SBR-PGZN-plus

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|-------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 200 | 0300015 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 200 | 0300025 | Steel (1.7131) | 1 |

Universal gripper

Tolerance compensation unit TCU




90 Monitoring of locking

Grippers can be directly mounted without an adapter plate. Tolerance compensation unit and gripper have an identical screw connection diagram. Therefore the tolerance compensation units can be assembled later. Please consider the additional assembly height of the tolerance compensation unit. For details please refer to our catalog robot accessories.

| Description | ID | Locking | Deflection | Often combined |
|-------------------|---------|---------|---------------|----------------|
| Compensation unit | | | | |
| TCU-P-200-3-MV | 0324864 | yes | ±1°/±2°/±1,5° | • |
| TCU-P-200-3-0V | 0324865 | no | ±1°/±2°/±1,5° | |

Inductive proximity switches




- 17) Cable outlet
- 91) Sensor IN..-SA
- 90 Sensor IN ...

Directly mounted end position monitoring.

| Description | ID | Often combined |
|-----------------------------------|-----------------|----------------|
| Inductive proximity switch | | |
| IN 80-S-M12 | 0301578 | |
| IN 80-S-M8 | 0301478 | • |
| INK 80-S | 0301550 | |
| Inductive proximity switch with I | ateral cable ou | tlet |
| IN 80-S-M12-SA | 0301587 | |
| IN 80-S-M8-SA | 0301483 | • |
| INK 80-S-SA | 0301566 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BG12-L 3P-0500-PNP | 30016369 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| KA BW12-L 3P-0300-PNP | 0301503 | |
| KA BW12-L 3P-0500-PNP | 0301507 | |
| Clip for connector/socket | | |
| CLI-M12 | 0301464 | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BG12-SG12 3P-0030-PNP | 0301999 | |
| KV BG12-SG12 3P-0060-PNP | 0301998 | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| KV BW12-SG12 3P-0030-PNP | 0301595 | |
| KV BW12-SG12 3P-0100-PNP | 0301596 | |
| KV BW12-SG12 3P-0200-PNP | 0301597 | |
| Sensor distributor | | |
| V2-M12 | 0301776 | • |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Flexible position sensor




- 90 FPS-S sensor
- 92 Cable extension
- (91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID |
|-------------------------|---------|
| Attachment kit for FPS | |
| AS-FPS-PGN-plus-P 200-1 | 1388827 |
| AS-FPS-PGN-plus-P 200-2 | 1388829 |
| Sensor | |
| FPS-S M8 | 0301704 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Cable extension | |
| KV BG08-SG08 3P-0050 | 0301598 |
| KV BG08-SG08 3P-0100 | 0301599 |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS




- 17) Cable outlet
- 91) Sensor MMS 22...-SA
- 90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|-----------------------------------|-----------------|----------------|
| Description | עו | orten combined |
| Electronic magnetic switch | | |
| MMS 22-S-M8-PNP | 0301032 | • |
| MMSK 22-S-PNP | 0301034 | |
| Electronic magnetic switches with | lateral cable o | outlet |
| MMS 22-S-M8-PNP-SA | 0301042 | • |
| MMSK 22-S-PNP-SA | 0301044 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| Sensor distributor | | |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1



(17) Cable outlet

(91) Sensor MMS 22 ..-PI1-...-SA


90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | | |
|---|------------------------------|----------------|--|--|--|--|
| Programmable magnetic switch | Programmable magnetic switch | | | | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • | | | | |
| MMSK 22-PI1-S-PNP | 0301162 | | | | | |
| Programmable magnetic switch | with lateral c | able outlet | | | | |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • | | | | |
| MMSK 22-PI1-S-PNP-SA | 0301168 | | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | | |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • | | | | |
| MMSK 22-PI1-S-PNP-HD | 0301112 | | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI2



(17) Cable outlet


90 MMS 22...-PI2-... sensor

Position monitoring with two programmable positions per sensor and electronics integrated in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | | |
|---|--|----------------|--|--|--|--|
| Programmable magnetic switch | Programmable magnetic switch | | | | | |
| MMS 22-PI2-S-M8-PNP | 0301180 | • | | | | |
| MMSK 22-PI2-S-PNP | 0301182 | | | | | |
| Programmable magnetic switch | Programmable magnetic switch with lateral cable outlet | | | | | |
| MMS 22-PI2-S-M8-PNP-SA | 0301186 | • | | | | |
| MMSK 22-PI2-S-PNP-SA | 0301188 | | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | | |
| MMS 22-PI2-S-M8-PNP-HD | 0301130 | • | | | | |
| MMSK 22-PI2-S-PNP-HD | 0301132 | | | | | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

MMS-P programmable magnetic switch




(74) Limit stop for sensor

Position monitoring with two programmable positions per sensor. End position monitoring for mounting in the C-slot.

| Description | ID | Often combined | | | | |
|------------------------------|------------------------------|----------------|--|--|--|--|
| Programmable magnetic switch | Programmable magnetic switch | | | | | |
| MMSK-P 22-S-PNP | 0301371 | | | | | |
| MMS-P 22-S-M8-PNP | 0301370 | • | | | | |
| Connection cables | | | | | | |
| KA GLN0804-LK-00500-A | 0307767 | • | | | | |
| KA GLN0804-LK-01000-A | 0307768 | | | | | |
| KA WLN0804-LK-00500-A | 0307765 | | | | | |
| KA WLN0804-LK-01000-A | 0307766 | | | | | |
| Clip for connector/socket | | | | | | |
| CLI-M8 | 0301463 | | | | | |
| Sensor distributor | | | | | | |
| V2-M8-4P-2XM8-3P | 0301380 | | | | | |

① One sensor is required per unit for monitoring two positions. Extension cables and sensor distributors are optionally available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor systems.

Analog position sensor MMS-A




74) Limit stop for sensor

Non-contact measuring, analog multi-position monitoring for any number of positions, easy to assemble in the C-slot. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the chart provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-10V-M08 | 0315825 |
| MMS 22-A-10V-M12 | 0315828 |

① One sensor is required per unit. The output voltage of the sensor differs according to the unit and is typically between 0.3 and 10 V. The resolution of the sensor can be smaller in the peripheral areas of the gripper. For further information on the product, see operating manual.

Flexible position sensor with MMS-A




- (74) Limit stop for sensor
- 91) FPS-F5 evaluation electronic
- 90 MMS 22-A-... sensor
- (92) Connection cables

Flexible position monitoring of up to five positions. Sensor can be taught using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID |
|------------------------|---------|
| Analog position sensor | |
| MMS 22-A-05V-M08 | 0315805 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Sensor Teaching Tool | |
| MT-MMS 22-PI | 0301030 |
| Connection cables | |
| KA BG16-L 12P-1000 | 0301801 |

When using an FPS system, one MMS 22-A-05V and one evaluation electronics (FPS-F5) are required per each gripper, as well as an attachment kit (AS), if listed. On option, cable extensions (KV) are available – see catalog chapter "Accessories." The resolution of the sensor can be lower in the peripheral areas of the gripper. Further information on the product can be found in the operating manual.

Programmable magnetic switch MMS-I0-Link




74) Limit stop for sensor

Sensor for multi-position monitoring through detection of the complete gripper stroke. The sensor is mounted directly in the C-slot of the gripper. The sensor is programmed for the gripper via the IO-Link interface, Magnet teaching tool MT (included in scope of delivery; ID 0301030) or the ST plug teaching tool (not included in scope of delivery; ID 0301026). An IO-Link master is required for operation.

| Description | ID |
|------------------|--------------|
| Programmable mag | netic switch |
| MMS 22-I0L-M08 | 0315830 |
| MMS 22-I0L-M12 | 0315835 |

① One sensor is required for each gripper. No additional mounting kit is required – the gripper is equipped for use of the sensor by default. Further information and technical data can be found in the catalog chapter sensor systems.

APS-Z80 analog position sensor




Non-contact measuring, analog multi-position monitoring for any number of positions.

| Description | ID | Often combined |
|-----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 200-1 | 1374183 | |
| AS-APS-Z80-PGN-plus-P 200-2 | 1374184 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |


When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 240-1 | PGN-plus-P 240-2 | PGN-plus-P 240-1-AS | PGN-plus-P 240-2-AS | PGN-plus-P 240-1-IS | PGN-plus-P 240-2-IS |
|------------------------------------|-------|---------------------|---------------------|------------------------|------------------------|------------------------|------------------------|
| ID | | 0318640 | 0318641 | 0318642 | 0318643 | 0318644 | 0318645 |
| Stroke per jaw | [mm] | 30 | 17 | 30 | 17 | 30 | 17 |
| Closing/opening force | [N] | 5300/5600 | 9000/9500 | 7800/- | 14000/- | -/8300 | -/14500 |
| Min. spring force | [N] | | | 2500 | 5000 | 2700 | 5000 |
| Weight | [kg] | 8.6 | 8.9 | 11.6 | 11.9 | 11.3 | 11.6 |
| Recommended workpiece weight | [kg] | 26.5 | 45 | 26.5 | 45 | 26.5 | 45 |
| Cylinder volume per double stroke | [cm³] | 900 | 900 | 1300 | 1300 | 1400 | 1400 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.5/0.5 | 0.5/0.5 | 0.45/0.9 | 0.45/0.9 | 0.9/0.45 | 0.9/0.45 |
| Closing/opening time with spring | [s] | | | 0.60 | 0.60 | 0.60 | 0.60 |
| Max. permissible finger length | [mm] | 355 | 305 | 305 | 260 | 305 | 260 |
| Max. permissible weight per finger | [kg] | 9.5 | 9.5 | 9.5 | 9.5 | 9.5 | 9.5 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.04 | 0.04 | 0.04 | 0.04 | 0.04 | 0.04 |
| Dimensions X x Y x Z | [mm] | 270 x 115 x 107 | 270 x 115 x 107 | 270 x 115 x 163.5 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1317742 | 1317744 | 1317745 | 1317749 | 1317752 | 1317755 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 9.4 | 9.6 | 12.5 | 12.7 | 12.2 | 12.4 |
| Corrosion-protected version | | 1317732 | 1317735 | 1317737 | 1317738 | 1317739 | 1317740 |
| High-temperature version | | 1317715 | 1317717 | 1317722 | 1317724 | 1317725 | 1317729 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 1317758 | 1317759 | 1317760 | 1317761 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- 2 Finger connection
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 Sensor MMS 22..
- **91**) Sensor IN ...
- Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection






 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M5




The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.

Gripping force maintenance version AS/IS



The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- (9) For mounting screw connection diagram, see basic version
- 15) Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|--------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 240 | 1347587 |

The "dustproof" option can either be ordered as a pre-mounted gripper version or can be retrofitted to the gripper using the "SAD PGN-plus-P" retrofit kit.


Precision version



- 20 For version AS/IS
- 72 Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

SDV-P pressure maintenance valve




The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID | Recommended hose diameter | |
|---|---------|---------------------------|--|
| | | [mm] | |
| Pressure maintenance | e valve | | |
| SDV-P 07 | 0403131 | 8 | |
| Pressure maintenance valve with air bleed screw | | | |
| SDV-P 07-E | 0300121 | 8 | |
| SDV-P 10-E | 0300109 | 10 | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

BSWS jaw quick-change jaw systems



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | | | |
|-------------------------------|-------------------------------------|-------------------|--|--|--|--|
| Jaw quick-change system adapt | Jaw quick-change system adapter pin | | | | | |
| BSWS-A 240 | 0303034 | 2 | | | | |
| BSWS-AR 240 | 1453342 | 2 | | | | |
| Quick-change jaw system base | | | | | | |
| BSWS-B 240 | 0303035 | 1 | | | | |
| Jaw quick-change system | | | | | | |
| BSWS-ABR-PGZN-plus 240 | 1453348 | 1 | | | | |
| BSWS-UR 240 | 1451607 | 1 | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|-------------|--|----------------|--|
| PGN-plus-P | 240 | -1 (6 bar) | | |
| PGN-plus-P | 240 | -1-AS/1-IS (6 bar | | |
| PGN-plus-P | 240 | -2 (6 bar) | | |
| PGN-plus-P | 240 | -2-AS/2-IS (6 bar |) == □□ | |
| Legend | | | | |
| | Can be con | Can be combined without restrictions | | |
| | Use with re | Use with restrictions (see loading limits) | | |
| 0000 | cannot be | cannot be combined | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-M



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery |
|-------------------------------------|------------|-------------------|
| Jaw quick-char | nge system | |
| BSWS-BM 240 | 1470901 | 1 |
| Jaw quick-change system adapter pin | | |
| BSWS-A 240 | 0303034 | 2 |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|--|--------------------|-------------|--|
| PGN-plus-P | 240 | -1 (6 bar) | | |
| PGN-plus-P | 240 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 240 | -2 (6 bar) | | |
| PGN-plus-P | 240 | -2-AS/2-IS (6 bar) | | |
| Legend | | | | |
| | Can be combined without restrictions | | | |
| | Use with restrictions (see loading limits) | | | |
| 0000 | cannot be combined | | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-R



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | | | |
|-------------------------------------|----------------|-------------------|--|--|--|--|
| law quick-change system adapter pin | | | | | | |
| BSWS-AR 240 | 1453342 | 2 | | | | |
| Storage system | Storage system | | | | | |
| BSWS-SR 240 | 1555978 | 1 | | | | |
| Quick-change jaw system base | | | | | | |
| BSWS-BR 240 | 1555943 | 1 | | | | |
| Attachment kit for proximity switch | | | | | | |
| AS-IN80-BSWS-SR 240/300 | 1561481 | | | | | |
| Inductive proximity switch | | | | | | |
| IN 80-S-M12 | 0301578 | | | | | |
| IN 80-S-M8 | 0301478 | | | | | |
| INK 80-S | 0301550 | | | | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|---------------|--|-------------|--|
| PGN-plus-P | 240 | -1 (6 bar) | | |
| PGN-plus-P | 240 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 240 | -2 (6 bar) | | |
| PGN-plus-P | 240 | -2-AS/2-IS (6 bar | | |
| Legend | | | | |
| | Can be comb | Can be combined without restrictions | | |
| | Use with rest | Use with restrictions (see loading limits) | | |
| | cannot be co | cannot be combined | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

ZBA-L-plus 240 intermediate jaws




- 2 Finger connection
- (56) Included in the scope of delivery
- 72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- (81) Not included in the scope of delivery

The optional ZBA-L-plus intermediate jaws allow the screw connection diagram of the top jaws to be rotated by 90°. This makes it easier to design and produce top jaws (particularly for long versions) because no deep through-bores are required.

| Description | ID | Material | Finger interface | Scope of delivery |
|------------------|---------|----------|---------------------|-------------------|
| Intermediate jaw | | | | |
| ZBA-L-plus 240 | 0311782 | Aluminum | PGN-plus 240 | 1 |

Tolerance compensation unit TCU




90 Monitoring of locking

Grippers can be directly mounted without an adapter plate. Tolerance compensation unit and gripper have an identical screw connection diagram. Therefore the tolerance compensation units can be assembled later. Please consider the additional assembly height of the tolerance compensation unit. For details please refer to our catalog robot accessories.

| Description | ID | Locking | Deflection | Often combined |
|-------------------|---------|---------|---------------|----------------|
| Compensation unit | | | | |
| TCU-P-240-3-MV | 0324730 | yes | ±1°/±1,5°/±1° | • |
| TCU-P-240-3-0V | 0324731 | no | ±1°/±1,5°/±1° | |

Finger blanks ABR/SBR-PGZN-plus 240




(2) Finger connection

(72) Fit for centering sleeves

The drawing shows the finger blank which can be reworked by the customer.

| Description | ID | Material | Scope of delivery |
|-------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 240 | 0300017 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 240 | 0300027 | Steel (1.7131) | 1 |

Inductive proximity switches



- $\widehat{17}$ Cable outlet
- 91) Sensor IN..-SA
- 90 Sensor IN ...

Directly mounted end position monitoring.


| Description | ID | Often combined | | |
|--|----------|----------------|--|--|
| Inductive proximity switch | | | | |
| IN 80-S-M12 | 0301578 | | | |
| IN 80-S-M8 | 0301478 | • | | |
| INK 80-S | 0301550 | | | |
| Inductive proximity switch with lateral cable outlet | | | | |
| IN 80-S-M12-SA | 0301587 | | | |
| IN 80-S-M8-SA | 0301483 | • | | |
| INK 80-S-SA | 0301566 | | | |
| Connection cables | | | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • | | |
| KA BG08-L 3P-0500-PNP | 0301623 | | | |
| KA BG12-L 3P-0500-PNP | 30016369 | | | |
| KA BW08-L 3P-0300-PNP | 0301594 | | | |
| KA BW08-L 3P-0500-PNP | 0301502 | | | |
| KA BW12-L 3P-0300-PNP | 0301503 | | | |
| KA BW12-L 3P-0500-PNP | 0301507 | | | |
| Clip for connector/socket | | | | |
| CLI-M12 | 0301464 | | | |
| CLI-M8 | 0301463 | | | |
| Cable extension | | | | |
| KV BG12-SG12 3P-0030-PNP | 0301999 | | | |
| KV BG12-SG12 3P-0060-PNP | 0301998 | | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | | | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | | | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • | | |
| KV BW12-SG12 3P-0030-PNP | 0301595 | | | |
| KV BW12-SG12 3P-0100-PNP | 0301596 | | | |
| KV BW12-SG12 3P-0200-PNP | 0301597 | | | |
| Sensor distributor | | | | |
| V2-M12 | 0301776 | • | | |
| V2-M8 | 0301775 | • | | |
| V4-M8 | 0301746 | | | |
| V8-M8 | 0301751 | | | |
| @ T | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

PGN-plus-P 240

Universal gripper

Flexible position sensor



90 FPS-S sensor

92 Cable extension


(91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID | | |
|-------------------------|---------|--|--|
| Attachment kit for FPS | | | |
| AS-FPS-PGN-plus-P 240-1 | 1388834 | | |
| AS-FPS-PGN-plus-P 240-2 | 1388840 | | |
| Sensor | | | |
| FPS-S M8 | 0301704 | | |
| Evaluation electronics | | | |
| FPS-F5 | 0301805 | | |
| Cable extension | | | |
| KV BG08-SG08 3P-0050 | 0301598 | | |
| KV BG08-SG08 3P-0100 | 0301599 | | |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS



17) Cable outlet

91) Sensor MMS 22...-SA


90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| Description ID Electronic magnetic switch 0301032 MMS 22-S-M8-PNP 0301034 Electronic magnetic switches with lateral cabl 0301042 MMS 22-S-M8-PNP-SA 0301042 MMSK 22-S-PNP-SA 0301044 Connection cables | le outlet |
|--|--------------|
| MMSK 22-S-PNP 0301034 Electronic magnetic switches with lateral cabl MMS 22-S-M8-PNP-SA 0301042 MMSK 22-S-PNP-SA 0301044 | le outlet |
| Electronic magnetic switches with lateral cabl MMS 22-S-M8-PNP-SA 0301042 MMSK 22-S-PNP-SA 0301044 | le outlet |
| MMS 22-S-M8-PNP-SA 0301042 MMSK 22-S-PNP-SA 0301044 | le outlet • |
| MMSK 22-S-PNP-SA 0301044 | • |
| | |
| Connection cables | |
| | |
| KA BG08-L 3P-0300-PNP 0301622 | • |
| KA BG08-L 3P-0500-PNP 0301623 | |
| KA BW08-L 3P-0300-PNP 0301594 | |
| KA BW08-L 3P-0500-PNP 0301502 | |
| Clip for connector/socket | |
| CLI-M8 0301463 | |
| Cable extension | |
| KV BW08-SG08 3P-0030-PNP 0301495 | |
| KV BW08-SG08 3P-0100-PNP 0301496 | |
| KV BW08-SG08 3P-0200-PNP 0301497 | • |
| Sensor distributor | |
| V2-M8 0301775 | • |
| V4-M8 0301746 | |
| V8-M8 0301751 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1



(17) Cable outlet

91) Sensor MMS 22 ..-PI1-...-SA


90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined | | | |
|---|----------------|----------------|--|--|--|
| Programmable magnetic switch | | | | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • | | | |
| MMSK 22-PI1-S-PNP | 0301162 | | | | |
| Programmable magnetic switch | with lateral c | able outlet | | | |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • | | | |
| MMSK 22-PI1-S-PNP-SA | 0301168 | | | | |
| Programmable magnetic switch with stainless steel housing | | | | | |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • | | | |
| MMSK 22-PI1-S-PNP-HD | 0301112 | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

APS-Z80 analog position sensor




Non-contact measuring, analog multi-position monitoring for any number of positions.

| Description | ID | Often combined |
|-----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 240-1 | 1374185 | |
| AS-APS-Z80-PGN-plus-P 240-2 | 1374186 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |


When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 300-1 | PGN-plus-P 300-2 | PGN-plus-P 300-1-AS | PGN-plus-P 300-2-AS | PGN-plus-P 300-1-IS | PGN-plus-P 300-2-IS |
|------------------------------------|-------|---------------------|---------------------|------------------------|------------------------|------------------------|------------------------|
| ID | | 1377846 | 1377878 | 1377881 | 1377887 | 1377888 | 1377889 |
| Stroke per jaw | [mm] | 35 | 20 | 35 | 20 | 35 | 20 |
| Closing/opening force | [N] | 6600/6800 | 11800/12200 | 8200/- | 15600/- | -/8400 | -/16000 |
| Min. spring force | [N] | | | 1600 | 3800 | 1600 | 3800 |
| Weight | [kg] | 13.7 | 13.7 | 17.2 | 17.2 | 17.2 | 17.2 |
| Recommended workpiece weight | [kg] | 33 | 59 | 33 | 59 | 33 | 59 |
| Cylinder volume per double stroke | [cm³] | 1040 | 1040 | 1295 | 1295 | 1560 | 1560 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.5/0.5 | 0.5/0.5 | 0.4/0.7 | 0.4/0.7 | 0.7/0.4 | 0.7/0.4 |
| Closing/opening time with spring | [s] | | | 0.60 | 0.60 | 0.60 | 0.60 |
| Max. permissible finger length | [mm] | 350 | 300 | 300 | 250 | 300 | 250 |
| Max. permissible weight per finger | [kg] | 11.5 | 11.5 | 11.5 | 11.5 | 11.5 | 11.5 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.05 | 0.05 | 0.05 | 0.05 | 0.05 | 0.05 |
| Dimensions X x Y x Z | [mm] | 320 x 140 x 122 | 320 x 140 x 122 | 320 x 140 x 172 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1377936 | 1377942 | 1377947 | 1377950 | 1377951 | 1377958 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 15.2 | 15.2 | 18.7 | 18.7 | 18.7 | 18.7 |
| Corrosion-protected version | | 1377922 | 1377923 | 1377927 | 1377928 | 1377930 | 1377933 |
| High-temperature version | | 1377892 | 1377896 | 1377903 | 1377912 | 1377919 | 1377920 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 1377966 | 1377973 | 1377980 | 1377986 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- (2) Finger connection
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 MMS 22 sensor
- **91**) Sensor IN ...
- ©2 Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection





 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.


Hose-free direct connection M5



3 Adapter
4 Grippers


The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.

Gripping force maintenance version AS/IS



The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- 9 For mounting screw connection diagram, see basic version
- (15) Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|--------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 300 | 1347590 |

SDV-P pressure maintenance valve



(4) Grippers


90 SDV-P pressure maintenance valve

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description ID | | Recommended hose diameter | |
|---|---------|---------------------------|--|
| | | [mm] | |
| Pressure maintenance | e valve | | |
| SDV-P 07 | 0403131 | 8 | |
| Pressure maintenance valve with air bleed screw | | | |
| SDV-P 07-E | 0300121 | 8 | |
| SDV-P 10-E | 0300109 | 10 | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

Precision version




- 20 For version AS/IS
- (72) Fit for centering sleeves
- (80) Depth of the centering sleeve hole in the counter part

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

PGN-plus-P 300

Universal gripper

BSWS jaw quick-change jaw systems



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | | |
|-------------------------------------|---------|-------------------|--|--|
| Jaw quick-change system adapter pin | | | | |
| BSWS-A 300 | 0303036 | 2 | | |
| BSWS-AR 300 | 1453343 | 2 | | |
| Quick-change jaw system base | | | | |
| BSWS-B 300 | 0303037 | 1 | | |
| Jaw quick-change system | | | | |
| BSWS-ABR-PGZN-plus 300 | 1453349 | 1 | | |
| BSWS-UR 300 | 1451608 | 1 | | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Size | Variant | Suitability |
|--|--|--|
| 300 | -1 (6 bar) | |
| 300 | -1-AS/1-IS (6 bar) | |
| 300 | -2 (6 bar) | |
| 300 | -2-AS/2-IS (6 bar) | 0000 |
| | | |
| Can be combined without restrictions | | |
| Use with restrictions (see loading limits) | | |
| cannot be combined | | |
| | 300 300 300 300 Can be combined w Use with restriction | 300 -1 (6 bar) 300 -1-AS/1-IS (6 bar) 300 -2 (6 bar) 300 -2-AS/2-IS (6 bar) Can be combined without restrictions Use with restrictions (see loading limit |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-M



(4) Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery | |
|-------------------------------------|------------|-------------------|--|
| Jaw quick-char | ige system | | |
| BSWS-BM 300 | 1462015 | 1 | |
| Jaw quick-change system adapter pin | | | |
| BSWS-A 300 | 0303036 | 2 | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability |
|------------|--|--------------------|-------------|
| PGN-plus-P | 300 | -1 (6 bar) | |
| PGN-plus-P | 300 | -1-AS/1-IS (6 bar) | |
| PGN-plus-P | 300 | -2 (6 bar) | |
| PGN-plus-P | 300 | -2-AS/2-IS (6 bar) | 0000 |
| Legend | | | |
| | Can be combined without restrictions | | |
| | Use with restrictions (see loading limits) | | |
| 0000 | cannot be combined | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Jaw quick-change system BSWS-R



4 Grippers

90 Customized gripper fingers

There are various jaw quick-change systems available for the gripper. For detailed information, please refer to the corresponding product.

| Description | ID | Scope of delivery |
|-----------------------------------|---------|-------------------|
| Jaw quick-change system adapte | r pin | |
| BSWS-AR 300 | 1453343 | 2 |
| Quick-change jaw system base | | |
| BSWS-BR 300 | 1555944 | 1 |
| Storage system | | |
| BSWS-SR 300 | 1555982 | 1 |
| Attachment kit for proximity swit | ch | |
| AS-IN80-BSWS-SR 240/300 | 1561481 | |
| Inductive proximity switch | | |
| IN 80-S-M12 | 0301578 | |
| IN 80-S-M8 | 0301478 | |
| INK 80-S | 0301550 | |


① If the operating pressure is higher than 6 bar, suitability for use beyond the application limits must be checked. Only systems that are listed in the table, can be used.

Fields of application

| Series | Size | Variant | Suitability | |
|------------|---------------|--|-------------|--|
| PGN-plus-P | 300 | -1 (6 bar) | | |
| PGN-plus-P | 300 | -1-AS/1-IS (6 bar) | | |
| PGN-plus-P | 300 | -2 (6 bar) | | |
| PGN-plus-P | 300 | -2-AS/2-IS (6 bar) | 0000 | |
| Legend | | | | |
| | Can be combi | Can be combined without restrictions | | |
| | Use with rest | Use with restrictions (see loading limits) | | |
| 0000 | cannot be co | cannot be combined | | |

The load limits for describing the application limits can be found in the catalog chapter of the corresponding accessories.

Finger blanks ABR/SBR-PGZN-plus 300




2 Finger connection

72 Fit for centering sleeves

The drawing shows the finger blank which can be reworked by the customer. $% \label{eq:customer} % \label{eq:customer}$

| Description | ID | Material | Scope of delivery |
|-------------------|---------|-------------------|-------------------|
| Finger blank | | | |
| ABR-PGZN-plus 300 | 0300016 | Aluminum (3.4365) | 1 |
| SBR-PGZN-plus 300 | 0300026 | Steel (1.7131) | 1 |

Inductive proximity switches



17) Cable outlet

91) Sensor IN..-SA


90 Sensor IN ...

Directly mounted end position monitoring.

| · · | | | | | |
|------------------------------------|----------------|----------------|--|--|--|
| Description | ID | Often combined | | | |
| nductive proximity switch | | | | | |
| IN 80-S-M12 | 0301578 | | | | |
| IN 80-2-08 NI | 0301478 | • | | | |
| INK 80-S | 0301550 | | | | |
| Inductive proximity switch with la | teral cable ou | tlet | | | |
| IN 80-S-M12-SA | 0301587 | | | | |
| IN 80-S-M8-SA | 0301483 | • | | | |
| INK 80-S-SA | 0301566 | | | | |
| Connection cables | | | | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • | | | |
| KA BG08-L 3P-0500-PNP | 0301623 | | | | |
| KA BG12-L 3P-0500-PNP | 30016369 | | | | |
| KA BW08-L 3P-0300-PNP | 0301594 | | | | |
| KA BW08-L 3P-0500-PNP | 0301502 | | | | |
| KA BW12-L 3P-0300-PNP | 0301503 | | | | |
| KA BW12-L 3P-0500-PNP | 0301507 | | | | |
| Clip for connector/socket | | | | | |
| CLI-M12 | 0301464 | | | | |
| CLI-M8 | 0301463 | | | | |
| Cable extension | | | | | |
| KV BG12-SG12 3P-0030-PNP | 0301999 | | | | |
| KV BG12-SG12 3P-0060-PNP | 0301998 | | | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | | | | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | | | | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • | | | |
| KV BW12-SG12 3P-0030-PNP | 0301595 | | | | |
| KV BW12-SG12 3P-0100-PNP | 0301596 | | | | |
| KV BW12-SG12 3P-0200-PNP | 0301597 | | | | |
| Sensor distributor | | | | | |
| V2-M12 | 0301776 | • | | | |
| V2-M8 | 0301775 | • | | | |
| V4-M8 | 0301746 | | | | |
| V8-M8 | 0301751 | | | | |
| | | | | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Flexible position sensor



90 FPS-S sensor

92 Cable extension


(91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID |
|-------------------------|---------|
| Attachment kit for FPS | |
| AS-FPS-PGN-plus-P 300-2 | 1395867 |
| Sensor | |
| FPS-S M8 | 0301704 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Cable extension | |
| KV BG08-SG08 3P-0050 | 0301598 |
| KV BG08-SG08 3P-0100 | 0301599 |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS



17) Cable outlet

91) Sensor MMS 22...-SA


90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| . 1 | | |
|-----------------------------------|-----------------|----------------|
| Description | ID | Often combined |
| Electronic magnetic switch | | |
| MMS 22-S-M8-PNP | 0301032 | • |
| MMSK 22-S-PNP | 0301034 | |
| Electronic magnetic switches with | lateral cable o | outlet |
| MMS 22-S-M8-PNP-SA | 0301042 | • |
| MMSK 22-S-PNP-SA | 0301044 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| Sensor distributor | | |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |
| | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1




- (17) Cable outlet
- 91) Sensor MMS 22 ..-PI1-...-SA
- 90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined |
|------------------------------|----------------|-----------------|
| Programmable magnetic switch | | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • |
| MMSK 22-PI1-S-PNP | 0301162 | |
| Programmable magnetic switch | with lateral c | able outlet |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • |
| MMSK 22-PI1-S-PNP-SA | 0301168 | |
| Programmable magnetic switch | with stainless | s steel housing |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • |
| MMSK 22-PI1-S-PNP-HD | 0301112 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available.
Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

APS-Z80 analog position sensor



Non-contact measuring, analog multi-position monitoring for any number of positions.


| Description | ID | Often combined |
|-----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 300-1 | 1395892 | |
| AS-APS-Z80-PGN-plus-P 300-2 | 1395894 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |

When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.


Universal gripper




Gripping force O.D. gripping



Gripping force I.D. gripping



Dimensions and maximum loads




The indicated moments and forces are statical values, apply for each base jaw and may appear simultaneously. Loads may additionally occur to the moment produced by the gripping force itself.

Technical data

| Description | | PGN-plus-P 380-1 | PGN-plus-P 380-2 | PGN-plus-P 380-1-AS | PGN-plus-P 380-2-AS | PGN-plus-P 380-1-IS | PGN-plus-P 380-2-IS |
|------------------------------------|-------|---------------------|---------------------|------------------------|------------------------|------------------------|------------------------|
| ID | | 1378012 | 1378019 | 1378022 | 1378029 | 1378035 | 1378037 |
| Stroke per jaw | [mm] | 45 | 26 | 45 | 26 | 45 | 26 |
| Closing/opening force | [N] | 10300/10800 | 19500/20400 | 13800/- | 26100/- | -/14300 | -/27000 |
| Min. spring force | [N] | | | 3500 | 6600 | 3500 | 6600 |
| Weight | [kg] | 26.5 | 27.5 | 36 | 37 | 36 | 37 |
| Recommended workpiece weight | [kg] | 51.5 | 97.5 | 51.5 | 97.5 | 51.5 | 97.5 |
| Cylinder volume per double stroke | [cm³] | 2275 | 2275 | 2705 | 2705 | 3175 | 3175 |
| Min./nom./max. operating pressure | [bar] | 2.5/6/8 | 2.5/6/8 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 | 4/6/6.5 |
| Min./max. air purge pressure | [bar] | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 | 0.5/1 |
| Closing/opening time | [s] | 0.6/0.6 | 0.6/0.6 | 0.5/0.8 | 0.5/0.8 | 0.8/0.5 | 0.8/0.5 |
| Closing/opening time with spring | [s] | | | 0.80 | 0.80 | 0.80 | 0.80 |
| Max. permissible finger length | [mm] | 400 | 350 | 350 | 300 | 350 | 300 |
| Max. permissible weight per finger | [kg] | 17 | 17 | 17 | 17 | 17 | 17 |
| IP protection class | | 40 | 40 | 40 | 40 | 40 | 40 |
| Min./max. ambient temperature | [°C] | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 | 5/90 |
| Repeat accuracy | [mm] | 0.05 | 0.05 | 0.05 | 0.05 | 0.05 | 0.05 |
| Dimensions X x Y x Z | [mm] | 410 x 170 x 155 | 410 x 170 x 155 | 410 x 170 x 226.5 |
| Options and their characteristics | | | | | | | |
| Dustproof version | | 1378074 | 1378108 | 1378110 | 1378111 | 1378114 | 1378118 |
| IP protection class | | 64 | 64 | 64 | 64 | 64 | 64 |
| Weight | [kg] | 29.3 | 30.3 | 38.8 | 39.8 | 38.8 | 39.8 |
| Corrosion-protected version | | 1378059 | 1378061 | 1378064 | 1378066 | 1378070 | 1378072 |
| High-temperature version | | 1378038 | 1378042 | 1378047 | 1378048 | 1378050 | 1378056 |
| Min./max. ambient temperature | [°C] | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 | 5/130 |
| Precision version | | 1378120 | 1378124 | 1378128 | 1378130 | | |

① It may take a few 100 gripping cycles until the full gripping force (as indicated in the data table) will be available.


Main view




The drawing shows the gripper in the basic version with closed jaws, without dimensional consideration of the options described below.

- As an alternative/in addition to spring-assisted mechanical gripping force maintenance, the SDV-P pressure maintenance valve can be used for I.D. and O.D. gripping (see "Accessories" section of catalog).
- A, a Main / direct connection, gripper opening
- B, b Main / direct connection, gripper closing
- S Air purge connection
- (1) Gripper connection
- (2) Finger connection
- (72) Fit for centering sleeves
- 80 Depth of the centering sleeve hole in the counter part
- 90 MMS 22 sensor
- (91) Sensor IN ...
- ©2 Screw connection with centering for customized mounting (these centering sleeves are not included in the scope of delivery)


Maximum permitted finger projection






 L^{max} is equivalent to the maximum permitted finger length, see the technical data table.

Hose-free direct connection M6




The direct connection is used for supplying compressed air without hoses. Instead, the pressure medium is fed through bore-holes in the mounting plate.

Gripping force maintenance version AS/IS



The mechanical gripping force maintenance device ensures that a minimum clamping force will be applied even if there is a drop in pressure. In the AS/S variant this acts as a closing force, in the IS variant as an opening force. Besides this, gripping force maintenance can be used to increase gripping force or for single actuated gripping.

Dustproof version




- 9 For mounting screw connection diagram, see basic version
- (15) Sealing bolt
- 20 For version AS/IS

The "dustproof" option increases the degree of protection against penetrating substances. The assembly diagram shifts by the height of the intermediate jaw. The finger length is still measured from the upper edge of the gripper housing.

| Description | ID |
|--------------------|---------|
| Dust cover | |
| SAD PGN-plus-P 380 | 1347597 |

SDV-P pressure maintenance valve



(4) Grippers


90 SDV-P pressure maintenance valve

The SDV-P pressure maintenance valve ensures in emergency STOP situations that the pressure in the piston chamber of pneumatic gripper, swivel, linear, and quick-change modules is temporarily maintained.

| Description | ID Recommended hose diameter | | | |
|---|------------------------------|------|--|--|
| | | [mm] | | |
| Pressure maintenance valve with air bleed screw | | | | |
| SDV-P 10-E | 0300109 | 10 | | |

① In order to achieve the specified closing and opening time for each gripper variant, the recommended hose diameter must be used. The direct allocation of the respective variant of the gripper for the respective SDV-P can be found at schunk.com.

Precision version




- 20 For version AS/IS
- 80 Depth of the centering sleeve hole in the counter part (72) Fit for centering sleeves

The indicated tolerances just refer to the variants of precision versions shown in the chart of technical specifications. All other variants of precision versions are available on request.

PGN-plus-P 380

Universal gripper

Inductive proximity switches



(17) Cable outlet


90 Sensor IN ...

Directly mounted end position monitoring.

| Description | ID | Often combined |
|----------------------------|----------|----------------|
| Inductive proximity switch | | |
| IN 80-S-M12 | 0301578 | |
| IN 80-S-M8 | 0301478 | • |
| INK 80-S | 0301550 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BG12-L 3P-0500-PNP | 30016369 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| KA BW12-L 3P-0300-PNP | 0301503 | |
| KA BW12-L 3P-0500-PNP | 0301507 | |
| Clip for connector/socket | | |
| CLI-M12 | 0301464 | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BG12-SG12 3P-0030-PNP | 0301999 | |
| KV BG12-SG12 3P-0060-PNP | 0301998 | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| KV BW12-SG12 3P-0030-PNP | 0301595 | |
| KV BW12-SG12 3P-0100-PNP | 0301596 | |
| KV BW12-SG12 3P-0200-PNP | 0301597 | |
| Sensor distributor | | |
| V2-M12 | 0301776 | • |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |
| | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Flexible position sensor



90 FPS-S sensor

92 Cable extension


(91) FPS-F5 evaluation electronic

Flexible position monitoring of up to five positions.

| Description | ID |
|-------------------------|---------|
| Attachment kit for FPS | |
| AS-FPS-PGN-plus-P 380-2 | 1395872 |
| Sensor | |
| FPS-S M8 | 0301704 |
| Evaluation electronics | |
| FPS-F5 | 0301805 |
| Cable extension | |
| KV BG08-SG08 3P-0050 | 0301598 |
| KV BG08-SG08 3P-0100 | 0301599 |

When using an FPS system, an FPS sensor (FPS-S) as well as an electronic processor (FPS-F5 / F5 T) are required for each gripper as well as a mounting kit (AS), if listed. Cable extensions (KV) are optionally available – see catalog chapter "Accessories."

Electronic magnetic switch MMS



17) Cable outlet

91) Sensor MMS 22...-SA


90 Sensor MMS 22..

End position monitoring for mounting in the C-slot.

| Description | ID | Often combined |
|-----------------------------------|-----------------|----------------|
| Electronic magnetic switch | | |
| MMS 22-S-M8-PNP | 0301032 | • |
| MMSK 22-S-PNP | 0301034 | |
| Electronic magnetic switches with | lateral cable o | outlet |
| MMS 22-S-M8-PNP-SA | 0301042 | • |
| MMSK 22-S-PNP-SA | 0301044 | |
| Connection cables | | |
| KA BG08-L 3P-0300-PNP | 0301622 | • |
| KA BG08-L 3P-0500-PNP | 0301623 | |
| KA BW08-L 3P-0300-PNP | 0301594 | |
| KA BW08-L 3P-0500-PNP | 0301502 | |
| Clip for connector/socket | | |
| CLI-M8 | 0301463 | |
| Cable extension | | |
| KV BW08-SG08 3P-0030-PNP | 0301495 | |
| KV BW08-SG08 3P-0100-PNP | 0301496 | |
| KV BW08-SG08 3P-0200-PNP | 0301497 | • |
| Sensor distributor | | |
| V2-M8 | 0301775 | • |
| V4-M8 | 0301746 | |
| V8-M8 | 0301751 | |
| | | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

Programmable magnetic switch MMS 22-PI1




- (17) Cable outlet
- 91) Sensor MMS 22 ..-PI1-...-SA
- 90 Sensor MMS 22 PI1-...

Position monitoring with one programmable position per sensor and integrated electronic system in the sensor. Can be programmed using MT magnetic teaching tool (included in the scope of delivery, ID 0301030) or ST plug teaching tool (optional). End position monitoring for mounting in the C-slot. If the ST plug teaching tools are listed in the table provided, teaching is only possible with the ST teaching tools.

| Description | ID | Often combined |
|------------------------------|----------------|-----------------|
| Programmable magnetic switch | l | |
| MMS 22-PI1-S-M8-PNP | 0301160 | • |
| MMSK 22-PI1-S-PNP | 0301162 | |
| Programmable magnetic switch | with lateral c | able outlet |
| MMS 22-PI1-S-M8-PNP-SA | 0301166 | • |
| MMSK 22-PI1-S-PNP-SA | 0301168 | |
| Programmable magnetic switch | with stainles | s steel housing |
| MMS 22-PI1-S-M8-PNP-HD | 0301110 | • |
| MMSK 22-PI1-S-PNP-HD | 0301112 | |

Two sensors are required per unit for monitoring two positions. On option, extension cables and sensor distributors are available. Additional product variants of the sensor, and further information and technical data can be found in the catalog chapter sensor system.

APS-Z80 analog position sensor



Non-contact measuring, analog multi-position monitoring for any number of positions.

| Description | ID | Often combined |
|-----------------------------|---------|----------------|
| Mounting kit for APS-Z80 | | |
| AS-APS-Z80-PGN-plus-P 380-1 | 1395900 | |
| AS-APS-Z80-PGN-plus-P 380-2 | 1395903 | |
| Analog position sensor | | |
| APS-Z80-K | 0302072 | |
| APS-Z80-M8 | 0302070 | • |

When using an APS system, one mounting kit (AS-APS-Z80) and one APS-Z80 sensor is required per gripper. The resolution of the sensor can be lower in the peripheral areas of the gripper. You can find further information on the product in the operating manual.

Universal gripper



SCHUNK GmbH & Co. KG Spann- und Greiftechnik

Bahnhofstr. 106 - 134 D-74348 Lauffen/Neckar Tel. +49-7133-103-0 Fax +49-7133-103-2399 info@de.schunk.com schunk.com

Folgen Sie uns | Follow us









